

Publication 1041 (Iss.2)
April 2023
Part No. 24215.41
Revision: 27.08.25



McCONEL

ROBOCUT / T500

REMOTE CONTROLLED TRACTOR UNIT

Buils with Autec Remote Control (S/No: M2583111 onwards)

Operator Manual



IMPORTANT

VERIFICATION OF WARRANTY REGISTRATION



Dealer Warranty Information & Registration Verification

It is imperative that the selling dealer registers this machine with McConnel Limited before delivery to the end user – failure to do so may affect the validity of the machine warranty.

To register machines; log onto <https://my.mcconnel.com> and select 'Machine Registration' which can be found in the 'Warranty' section of the site. **Confirm to the customer that the machine has been registered by completing the verification form below.**

Registration Verification	Serial No.
Dealer Name:	
Dealer Address:	
Customer Name:	
Date of Warranty Registration:/...../..... Dealer Signature:	

Note to Customer / Owner

Please ensure the section above has been completed and signed by the dealer to verify your machine has been registered with McConnel Limited.

IMPORTANT: During the initial 'bedding in' period of a new machine it is the customer's responsibility to regularly inspect all nuts, bolts and hose connections for tightness and re-tighten if required. New hydraulic connections occasionally weep small amounts of oil as the seals and joints settle in – where this occurs it can be cured by re-tightening the connection – *refer to torque settings chart below*. The tasks stated above should be performed on an hourly basis during the first day of work and at least daily thereafter as part of the machine's general maintenance procedure.

CAUTION: DO NOT OVER TORQUE HYDRAULIC FITTINGS AND HOSES

Torque Settings for Hydraulic Fittings

Hydraulic Hose Ends		
BSP	Setting	Metric
1/4"	18 Nm	19 mm
3/8"	31 Nm	22 mm
1/2"	49 Nm	27 mm
5/8"	60 Nm	30 mm
3/4"	80 Nm	32 mm
1"	125 Nm	41 mm
1.1/4"	190 Nm	50 mm
1.1/2"	250 Nm	55 mm
2"	420 Nm	70 mm

Port Adaptors with Bonded Seals		
BSP	Setting	Metric
1/4"	34 Nm	19 mm
3/8"	47 Nm	22 mm
1/2"	102 Nm	27 mm
5/8"	122 Nm	30 mm
3/4"	149 Nm	32 mm
1"	203 Nm	41 mm
1.1/4"	305 Nm	50 mm
1.1/2"	305 Nm	55 mm
2"	400 Nm	70 mm

WARRANTY POLICY

WARRANTY REGISTRATION

All machines must be registered, by the selling dealer with McConnel Ltd, before delivery to the end user. On receipt of the goods it is the buyer's responsibility to check that the Verification of Warranty Registration in the Operator's Manual has been completed by the selling dealer.

1. LIMITED WARRANTIES

- 1.01. *All mounted machines supplied by McConnel Ltd are warranted to be free from defects in material and workmanship from the date of sale to the original purchaser for a period of 12 months, unless a different period is specified.*
All Self Propelled Machines supplied by McConnel Ltd are warranted to be free from defects in material and workmanship from the date of sale to the original purchaser for a period of 12 months or 1500 hours. Engine warranty will be specific to the Manufacturer of that unit.
- 1.02. *All spare parts supplied by McConnel Ltd and purchased by the end user are warranted to be free from defects in material and workmanship from the date of sale to the original purchaser for a period of 6 months. All parts warranty claims must be supported by a copy of the failed part invoice to the end user. We cannot consider claims for which sales invoices are not available.*
- 1.03. *The warranty offered by McConnel Ltd is limited to the making good by repair or replacement for the purchaser any part or parts found, upon examination at its factory, to be defective under normal use and service due to defects in material or workmanship. Returned parts must be complete and unexamined. Pack the component(s) carefully so that any transit damage is avoided. All ports on hydraulic items should be drained of oil and securely plugged to prevent seepage and foreign body ingress. Certain other components, electrical items for example, may require particular care when packing to avoid damage in transit.*
- 1.04. *This warranty does not extend to any product from which McConnel Ltd's serial number plate has been removed or altered.*
- 1.05. *The warranty policy is valid for machines registered in line with the terms and conditions detailed and on the basis that the machines do not extend a period of 24 months or greater since their original purchase date, that is the original invoice date from McConnel Limited.*
Machines that are held in stock for more than 24 months cannot be registered for warranty.
- 1.06. *This warranty does not apply to any part of the goods, which has been subjected to improper or abnormal use, negligence, alteration, modification, fitment of non-genuine parts, accident damage, or damage resulting from contact with overhead power lines, damage caused by foreign objects (e.g. stones, iron, material other than vegetation), failure due to lack of maintenance, use of incorrect oil or lubricants, contamination of the oil, or which has served its normal life. This warranty does not apply to any expendable items such as blades, belts, clutch linings, filter elements, flails, flap kits, skids, soil engaging parts, shields, guards, wear pads, pneumatic tyres or tracks.*
- 1.07. *Temporary repairs and consequential loss - i.e. oil, downtime and associated parts are specifically excluded from the warranty.*
- 1.08. *Warranty on hoses is limited to 12 months and does not include hoses which have suffered external damage. Only complete hoses may be returned under warranty, any which have been cut or repaired will be rejected.*
- 1.09. *Machines must be repaired immediately a problem arises. Continued use of the machine after a problem has occurred can result in further component failures, for which McConnel Ltd cannot be held liable, and may have safety implications.*
- 1.10. *If in exceptional circumstances a non McConnel Ltd part is used to effect a repair, warranty reimbursement will be at no more than McConnel Ltd's standard dealer cost for the genuine part.*

- 1.11. *Except as provided herein, no employee, agent, dealer or other person is authorised to give any warranties of any nature on behalf of McConnel Ltd.*
- 1.12. *For machine warranty periods in excess of 12 months the following additional exclusions shall apply:*
 - 1.12.1. *Hoses, exposed pipes and hydraulic tank breathers.*
 - 1.12.2. *Filters.*
 - 1.12.3. *Rubber mountings.*
 - 1.12.4. *External electric wiring.*
 - 1.12.5. *Bearings and seals*
 - 1.12.6. *External Cables, Linkages*
 - 1.12.7. *Loose/Corroded Connections, Light Units, LED's*
 - 1.12.8. *Comfort items such as Operator Seat, Ventilation, Audio Equipment*
- 1.13. *All service work, particularly filter changes, must be carried out in accordance with the manufacturer's service schedule. Failure to comply will invalidate the warranty. In the event of a claim, proof of the service work being carried out may be required.*
- 1.14. *Repeat or additional repairs resulting from incorrect diagnosis or poor quality previous repair work are excluded from warranty.*

NB Warranty cover will be invalid if any non-genuine parts have been fitted or used. Use of non-genuine parts may seriously affect the machine's performance and safety. McConnel Ltd cannot be held responsible for any failures or safety implications that arise due to the use of non-genuine parts.

2. REMEDIES AND PROCEDURES

- 2.01. *The warranty is not effective unless the Selling Dealer registers the machine, via the McConnel web site and confirms the registration to the purchaser by completing the confirmation form in the operator's manual.*
- 2.02. *Any fault must be reported to an authorised McConnel Ltd dealer as soon as it occurs. Continued use of a machine, after a fault has occurred, can result in further component failure for which McConnel Ltd cannot be held liable.*
- 2.03. *Repairs should be undertaken within two days of the failure. Claims submitted for repairs undertaken more than 2 weeks after a failure has occurred, or 2 days after the parts were supplied will be rejected, unless the delay has been authorised by McConnel Ltd. Please note that failure by the customer to release the machine for repair will not be accepted as a reason for delay in repair or submitting warranty claims.*
- 2.04. *All claims must be submitted, by an authorised McConnel Ltd Service Dealer, within 30 days of the date of repair.*
- 2.05. *Following examination of the claim and parts, McConnel Ltd will pay, at their discretion, for any valid claim the invoiced cost of any parts supplied by McConnel Ltd and appropriate labour and mileage allowances if applicable.*
- 2.06. *The submission of a claim is not a guarantee of payment.*
- 2.07. *Any decision reached by McConnel Ltd. is final.*

3. LIMITATION OF LIABILITY

- 3.01. *McConnel Ltd disclaims any express (except as set forth herein) and implied warranties with respect to the goods including, but not limited to, merchantability and fitness for a particular purpose.*
- 3.02. *McConnel Ltd makes no warranty as to the design, capability, capacity or suitability for use of the goods.*
- 3.03. *Except as provided herein, McConnel Ltd shall have no liability or responsibility to the purchaser or any other person or entity with respect to any liability, loss, or damage caused or alleged to be caused directly or indirectly by the goods including, but not limited to, any indirect, special, consequential, or incidental damages resulting from the use or operation of the goods or any breach of this warranty. Notwithstanding the above limitations and warranties, the manufacturer's liability hereunder for damages incurred by the purchaser or others shall not exceed the price of the goods.*
- 3.04. *No action arising out of any claimed breach of this warranty or transactions under this warranty may be brought more than one (1) year after the cause of the action has occurred.*

4. MISCELLANEOUS

- 4.01. McConnel Ltd may waive compliance with any of the terms of this limited warranty, but no waiver of any terms shall be deemed to be a waiver of any other term.*
- 4.02. If any provision of this limited warranty shall violate any applicable law and is held to be unenforceable, then the invalidity of such provision shall not invalidate any other provisions herein.*
- 4.03. Applicable law may provide rights and benefits to the purchaser in addition to those provided herein.*

McConnel Limited



For Safety and Performance...

ALWAYS READ THE BOOK FIRST



McCONNEL LIMITED

**Temeside Works
Ludlow
Shropshire
England**

**Telephone: +44 (0)1584 873131
www.mcconnel.com**



In line with our policy of constant improvement this publication may be periodically updated. To ensure you have access to the latest version of this manual please visit the manuals library on our website where an up-to-date version can be referenced online or downloaded.

To access manuals use the QR code opposite or the web address below;
<https://my.mcconnel.com/service/pdf-manuals/pdf-operator-manuals/remote-control-technology-manuals/>

SAFETY FIRST

MACHINE SAFETY DECALS MUST BE KEPT IN CLEAN READABLE CONDITION AT ALL TIMES;
Any safety decals that are missing, damaged or illegible must always be replaced immediately.
McConnel have a policy of providing replacement safety decals and manuals free of charge.

TABLE OF CONTENTS

1 - GENERAL DESCRIPTION

5

1.1 - PRELIMINARY INFORMATION	5
1.2 - TRAINING REQUIRED FROM THE OPERATOR	6
1.3 - WARNINGS ON USE AND STORAGE	6
1.4 - INTRODUCTION	7
1.4.1 - UPDATING THE MANUAL	7
1.4.2 - COPYRIGHT	7
1.5 - WARRANTIES	7
1.6 - RESPONSIBILITIES	8
1.7 - PERMITTED USES	8
1.8 - IMPROPER OR PROHIBITED USES	9
1.9 - RUNNING-IN AND TESTING THE MACHINE	10

2 - MACHINE SPECIFICATIONS

11

2.1 - MACHINE DESCRIPTION	11
2.2 - RULES APPLIED	12
2.3 - MACHINE IDENTIFICATION	13
2.3.1 - MACHINE DIRECTIONS	13
2.4 - NOISE LEVEL	14

3 - SAFETY REQUIREMENTS

15

3.1 - GENERAL SAFETY RULES	15
3.1.1 - GETTING TO KNOW THE MACHINE THOROUGHLY	15
3.1.2 - WEAR PROTECTIVE CLOTHING	16
3.1.3 - USE SAFETY EQUIPMENT	16
3.1.4 - WARNINGS FOR CHECKS AND MAINTENANCE	17
3.1.5 - CHECKING THE MACHINE	17
3.2 - GENERAL PRECAUTIONS	18
3.2.1 - SAFETY WARNINGS	18
3.2.2 - OPERATIONAL SAFETY	19
3.2.3 - SAFETY WHEN USING GRASS MOWING EQUIPMENT	19
3.2.4 - SAFETY REQUIREMENTS FOR THE HYDRAULIC SYSTEM	20
3.2.5 - LOCATION OF THE SAFETY SIGNS	21
3.2.6 - DESCRIPTION OF THE SAFETY SIGNS	22
3.2.7 - PRECAUTIONS REGARDING THE EQUIPMENT	24
3.3 - GENERAL SAFETY RULES	24
3.3.1 - CARE AND MAINTENANCE	24
3.3.2 - SAFETY DURING REFUELLING AND TOPPING UP	25
3.4 - MAINTENANCE PRECAUTIONS	25
3.4.1 - WARNING SIGNS	25
3.4.2 - TOOLS	25
3.4.3 - PERSONNEL	26
3.4.4 - WORKING UNDER THE MACHINE	26
3.4.5 - KEEPING THE MACHINE CLEAN	26
3.4.6 - PERIODICAL REPLACEMENT OF THE MAIN SAFETY COMPONENTS	27
3.4.7 - HYDRAULIC SYSTEM	27

4 - TECHNICAL DATA**28**

4.1 - TECHNICAL SPECIFICATIONS	28
4.2 - MACHINE NAME	31

5 - TERMINOLOGY**33**

5.1 - DEFINITION OF TERMS USED	33
--------------------------------	----

6 - USE OF THE MACHINE**34**

6.1 - PRELIMINARY CHECKS	34
6.2 - CHECKS TO BE PERFORMED AT THE START OF EACH WORKING DAY	34
6.3 - CHECKING THE CHROME-PLATED PARTS	34
6.4 - RECEIVER UNIT	35
6.4.1 - RECEIVER UNIT DESCRIPTION	36
6.4.2 - RECEIVER IDENTIFICATION PLATES	36
6.4.3 - RECEIVER UNIT LIGHT SIGNALS	37
6.4.4 - SEVEN SEGMENT DISPLAY	38
6.4.5 - POWER LED	38
6.4.6 - STATUS LED	38
6.4.7 - RUN LED	39
6.4.8 - ERR LED	39
6.4.9 - SETUP LED	39
6.5 - TRANSMITTER UNIT	40
6.5.1 - TRANSMITTER SPECIFICATIONS	41
6.5.2 - TRANSMITTER DESCRIPTION	41
6.5.3 - TRANSMITTER UNIT IDENTIFICATION PLATES	42
6.5.4 - TRANSMITTER LIGHT AND AUDIBLE SIGNALS	43
6.5.5 - GREEN LED	43
6.5.6 - RED LED	44
6.5.7 - AUDIBLE SIGNALS	44
6.5.8 - M-KEY	44
6.5.9 - TRANSMITTER BATTERY	45
6.5.10 - BATTERY LOW	46
6.6 - START-UP	47
6.7 - STARTING THE MACHINE	48
6.7.1 - CONNECTING THE MACHINE AND TRANSMITTER	49
6.7.2 - STARTING THE ENGINE	50
6.7.3 - STOPPING THE ENGINE	51
6.7.4 - EMERGENCY STOP AND RESETTING THE MACHINE	52
6.8 - MOVEMENT CONTROL	53
6.8.1 - MOVING THE MACHINE FORWARDS AND BACKWARDS	53
6.8.2 - STEERING	53
6.8.3 - CONTROLLING THE ENGINE SPEED	53
6.8.4 - GEAR CHANGE SWITCH	53
6.8.5 - MACHINE DIRECTION CONTROLS SWAP	54
6.8.6 - SPEED POTENTIOMETER	54
6.8.7 - STEERING BIAS CONTROL	54
6.9 - REVERSIBLE FAN	55
6.10 - CONTROLLING THE LIFTER	56
6.10.1 - RAISING AND LOWERING	56
6.10.2 - FLOATING / SUSPENSION FUNCTION	56
6.10.3 - SUSPENSION	56

6.10.4 - FLOATING FUNCTION	57
6.11 - ATTACHING A TOOL	58
6.12 - EQUIPMENT CONTROLS	61
6.12.1 - ACTIVATING / DEACTIVATING THE PTO	61
6.12.2 - INCREASING / DECREASING THE PTO SPEED	61
6.12.3 - AUXILIARY SERVICES AUX 1	61
6.12.4 - AUXILIARY SERVICES AUX 2	62
6.12.5 - REAR AUXILIARY SERVICES AUX 3	62
6.12.6 - STARTING, CONTROLLING AND STOPPING THE MULCHING HEAD	63
6.13 - CONTROL PANEL	64
6.13.1 - LCD DISPLAY	64
6.13.2 - WARNING LIGHTS	66
6.13.3 - MACHINE HOURS COUNTER / MAINTENANCE SCREEN	68
6.13.4 - ALARM SCREENS	69
6.13.5 - FLATNESS SENSOR (OPTIONAL)	70
6.13.6 - CHANGE OPERATION MODE SCREEN (OPTIONAL)	70
6.13.7 - REGENERATION SCREEN	71
6.14 - FUSES AND RELAYS	72
6.14.1 - QPL - FUSES AND RELAYS	73
6.14.2 - FUSES AND RELAYS ENGINE POWERBOX	74
6.14.3 - FUSES AND RELAYS ENGINE	75
6.15 - EXHAUST GAS POST TREATMENT SYSTEM	76
6.15.1 - DPF OVERVIEW (DIESEL PARTICULATE FILTER)	76
6.15.2 - DPF MAINTENANCE	77
6.15.3 - REGENERATION	78
6.16 - USE OF THE MACHINE ON UNEVEN GROUND	79
6.17 - CONTROL STATION - OPERATOR WORK AREA	81
6.18 - ENGINE FAULTS	82
6.18.1 - USING DIAGNOSTIC TROUBLE CODES (DTC)	82
6.18.2 - SPN - FMI CODES	83
6.19 - MACHINE PROBLEMS	87
6.19.1 - TROUBLESHOOTING CONTROL UNIT LE70	87
6.19.2 - ELECTRICAL CIRCUIT	90
6.19.3 - HYDRAULIC SYSTEM	91
6.19.4 - TROUBLESHOOTING THE RADIO CONTROL	93

7 - TRANSPORTATION AND HANDLING

98

7.1 - LOADING AND UNLOADING OPERATIONS FOR ROAD TRAVEL	98
7.2 - LIFTING THE MACHINE	99
7.2.1 - LIFTING POINTS	99
7.3 - IF THE MACHINE BREAKS DOWN	100
7.4 - USING THE MANUAL CONTROL (OPTIONAL)	101
7.5 - STARTING WITH AN AUXILIARY BATTERY	102

8 - STORAGE

103

8.1 - FIRST USE OR COMMISSIONING AFTER A LONG PERIOD OF INACTIVITY	103
8.2 - DISMANTLING, DECOMMISSIONING	104

9 - MAINTENANCE

105

9.1 - INTRODUCTION	105
--------------------	-----

9.2 - GENERAL INSTRUCTIONS	105
9.3 - EXTRAORDINARY INTERVENTIONS	105
9.4 - FLUIDS AND GREASES	106
9.4.1 - LUBRICANTS TABLE	106
9.4.2 - COOLANT	107
9.4.3 - FUEL	108
9.5 - ENGINE MAINTENANCE	109
9.5.1 - CHECK ENGINE OIL LEVEL	109
9.5.2 - FILTER AND ENGINE OIL CHANGE	110
9.5.3 - COOLANT LEVEL CHECK	112
9.5.4 - COOLANT REPLACEMENT	113
9.5.5 - FUEL LEVEL CHECK	116
9.5.6 - DRAINAGE AND VENTING OF THE FUEL DECANter	117
9.5.7 - REPLACING THE FUEL DECANter CARTRIDGE	148
9.5.8 - DRAINAGE AND VENTING OF THE FUEL FILTER	120
9.5.9 - REPLACING THE FUEL FILTER	121
9.5.10 - CLEANING OR REPLACING AIR FILTERS	123
9.5.11 - CLEANING THE RADIATOR CASING AND THE RADIATOR	125
9.5.12 - V-BELT INSPECTION / TENSIONING	126
9.5.13 - REPLACING THE V-BELT	128
9.5.14 - REPLACING THE CASING VENT FILTER	129
9.6 - HYDRAULIC SYSTEM MAINTENANCE	130
9.6.1 - HYDRAULIC OIL LEVEL CHECK	130
9.6.2 - CHANGING THE HYDRAULIC OIL FILTER	131
9.6.3 - CHANGING THE HYDRAULIC OIL FILTER	135
9.7 - MAINTENANCE OF THE HYDRAULIC MOTORS AND HYDRAULIC VALVES	136
9.8 - MAINTENANCE OF THE ELECTRICAL SYSTEM	137
9.8.1 - CHECKING THE BATTERY CHARGE	138
9.9 - WHEEL DRIVE MAINTENANCE	140
9.9.1 - CHECKING THE TIGHTNESS OF THE SCREWS	140
9.10 - TRACK MAINTENANCE	141
9.10.1 - CHECKING THE TRACK TENSION PRESSURE	141
9.10.2 - REPLACING THE TRACK	143
9.10.3 - ROLLER WEAR CHECK	144
9.11 - MACHINE GREASING	145
9.11.1 - LIFTING DEVICE	146
9.11.2 - CHECKING THE CHROME-PLATED PARTS	146
9.12 - PERIODICAL REPLACEMENT OF THE SAFETY COMPONENTS	146
9.13 - MAINTENANCE OPERATIONS	147
9.13.1 - MAINTENANCE FREQUENCY	147

10 - INSTRUCTIONS FOR EMERGENCY SITUATIONS

149

10.1 - FIRE	149
10.2 - ASSISTING THE OPERATOR IN CASE OF ILLNESS	149
10.3 - MANUAL BRAKE RELEASE & TOWING	150
10.4 - TOWING	151

11 - TIGHTENING TABLES

152

11.1 - SCREW TIGHTENING TABLE	152
11.2 - FITTINGS TIGHTENING TABLE	152

12 - NOTES

153

1 - GENERAL DESCRIPTION

1.1 - PRELIMINARY INFORMATION

This is the machine use and maintenance instruction manual and is compliant under:

- Directive Machine 2006/42/EC and subsequent amendments and additions.
- Statutory instruments 2008 No. 1597.

Do not destroy or modify it and only supplement it with additional files.

Publication: **1041**
 Part No.: **24215.41**
 Issued: **04/2023 (Revised 08/2025)**
 Machine type: **Remote-controlled, self-propelled machine**
 Model: **T500**

The manual is valid from serial number: **M2583111**

McConnel Limited, Temeside Works, Ludlow, Shropshire, SY8 1JL, UK

Tel: +44 (0)1584 873131 Email: sales@mcconnel.com Website: www.mcconnel.com

AS SUPPLIED (Hood Ram Spacer)

The flail head is fitted with a hydraulic ram to allow movement of the hinged hood. The movement of this ram is restricted with an internal spacer. This is to stop operators inadvertently opening the hood when cutting alongside the highway. This reduces the risk to passing traffic from being hit by objects ejected at speed from the working flail head. It should be noted that with the hinged hood opened objects could be thrown a considerable distance. Being struck by a thrown object could result in injury or death.

If the machine is being used away from the highway, other vehicles and bystanders are not normally in the vicinity then the spacer can be removed provided the general safety information and specific following conditions are met;

- A detailed work area and bystander risk assessment is undertaken before work begins.
- The operator has been trained in the safe use of the Robocut, including safe retrieval of the unit from any situation where it could become stuck or trapped.
- The hydraulic ram is returned to the approved version after usage away from the highway and before the re-sale to another party.

DANGER

Machines are supplied pre-fitted with an internal ram spacer to prevent inadvertent opening of the hood when working in the vicinity of highways and public areas – the ram spacer must be fitted at all times when operating the machine in these types of areas.



1.2 - TRAINING REQUIRED FROM THE OPERATOR

Reading this manual thoroughly:

- All machine maintenance personnel must read this entire manual thoroughly and pay maximum attention to its requirements.
- The employer has an obligation to ensure that the operator possesses the required abilities to operate the machine, and that they have read this manual.

1.3 - WARNINGS ON USE AND STORAGE

The operating instructions contained in this manual are valid exclusively for the McConnel machine, model: **Robocut T500**.

This instruction manual must be read and used as follows:

- Carefully read the instruction manual and consider it an integral part of the machine;
- The instruction manual must be readily accessible by the personnel assigned to operate it and to perform maintenance on it;
- This manual should be kept for the entire service life of the machine;
- Make sure that any received update is incorporated into the text;
- Pass on the manual to any other user or subsequent owner of the machine;
- Use the manual in such a way as not to damage it;
- Do not remove, tear or rewrite parts of the manual for any reason;
- Keep the manual in a place protected from moisture and heat;
- If the manual is lost or partially damaged and it is no longer possible to read its contents either partially/completely, it is advisable to request a new manual from the manufacturer.

Pay maximum attention to the following symbols and to their meanings. They serve to highlight particular information such as:

WARNING



With reference to additions or suggestions for the correct use of the machine.

ATTENTION



In reference to dangerous situations that may occur with the use of the machine and that could cause serious injury to persons or damage to property.

DANGER



With reference to dangerous situations that can occur when using the machine and which could cause severe injury or death if not avoided.

1.4 - INTRODUCTION

The service rules described in this manual are an integral part of the machine supply. These instructions are also addressed to operators already specifically trained to operate this kind of machinery and contain all the information necessary and essential for safe operation and for the correct/optimal use of the machine. Hurried and incomplete preparations may lead to improvisation and this is the cause of many accidents;

Before starting work, carefully read and thoroughly observe the following advice:

- Become familiar confident with all permissible operations and operating positions before starting to operate the machine;
- The operator must always have the instruction manual available at all times;
- Plan each intervention carefully;
- Obtain all the information necessary for machine road transport, such as distance, itinerary, height of level crossings, height of bridges, etc.;
- Be knowledgeable about where and how the machine should be operated: ground bearing weight, necessary outreach, mobility limitation due to the presence of buildings, power lines and similar;
- Before starting work, make sure that the safety devices work correctly and there is no doubt about their operation; otherwise, do not use the machine under any circumstances;
- When travelling by road, respect all the regulations and requirements in force on road traffic circulation;
- Carefully read the warnings relating to special hazards contained in this manual;
- Constant and thorough preventive maintenance always guarantees high operational safety of the machine. Never put off necessary repairs and ensure they are performed exclusively by specialised personnel, using only original spare parts.

1.4.1 - UPDATING THE MANUAL

The information, descriptions and illustrations contained in this manual reflect the state of the art at the time the machine was marketed.

The manufacturer reserves the right to make changes to the machines at any time for technical or commercial reasons. In the event that such changes are made, the manufacturer has no obligation (for safety reasons) to modify the other machines sold up to that point or to send updates for the manual. Moreover, this publication shall not be considered inadequate. Any additions that the manufacturer deems appropriate to provide as a result of the changes made must be kept with the manual and considered an integral part thereof.

1.4.2 - COPYRIGHT

The copyright of this manual belongs to the machine's manufacturer. This manual contains technical texts, drawings and illustrations which may not be divulged or transmitted to third parties, in whole or in part, without the written authorisation of the machine manufacturer.

1.5 - WARRANTIES

The parts supplied by McConnel are covered by a 12-month warranty, that becomes valid upon commissioning, proven by the documentation delivered to the customer. In any case, refer to the machine order confirmation or to any specific agreements entered into during the sale. McConnel shall repair or replace parts recognised as defective during the warranty period (see attached service log).

By replacing the defective part, McConnel shall consider itself free from any other expenses borne by the Dealer and the Dealer's Customer, for instance alleged damage, either present or future, such as lost earnings, conventional penalties, etc.

Ordinary and extraordinary maintenance must be performed in accordance with the instructions contained in this manual. For all cases not included and for every type of assistance, contact the company McConnel directly by registered letter or fax, even in the case of agreements made by telephone. The company McConnel shall not be held responsible for any delays or missed interventions. McConnel shall not be held responsible for any damage or malfunctions due to technical operations carried out on the machine by unauthorised personnel.

1.6 - RESPONSIBILITIES

McConnel considers itself exempted from all liability and obligations for accidents involving personal injuries or damage to property which may occur due to:

- Failure to observe the instructions given in this manual to run, operate and perform maintenance on the machine;
- Abrupt actions or incorrect manoeuvres when operating or performing maintenance on the machine;
- modifications made to the machine without prior written authorisation from McConnel;
- Any other events that cannot be considered normal and correct use of the machine.

In any case, whenever the user blames the accident on a defect of the machine, it is necessary to prove that the consequent damage was a main and direct consequence of such defect.

Any tampering or the use of non-original spare parts will create the conditions for voiding the warranty and put the operator's safety at risk.

ATTENTION



- **For repairs or maintenance always make exclusive use of original spare parts.**
- **McConnel declines all liability for any damage that may be caused as a result of non-compliance with the above.**
- **The machine is guaranteed according to the contractual agreements entered into upon sale.**
- **The warranty, however, will not apply if the rules and instructions of use contained in this manual have not been complied with.**

1.7 - PERMITTED USES

Robocut T500 is a machine built to be used by professional personnel. The machine is a self-propelled radio-controlled vehicle that can be used in the agricultural sector, with the possibility of attaching different tools to the front lifting equipment, as well as in the forestry sector.

Robocut T500 (from now referred to as machine) and the tools are not toys but a PROFESSIONAL MACHINE. Always respect the conditions of use specified by the producers of the machine. The machine is suitable for performing flail mowing operations at a speed of up to 4-5 km/h, depending on the conditions of the ground and the type and condition of material to be cut (length, whether dry or wet, density etc.) and on slopes having a maximum inclination of 50°.

This machine is generally used during daylight hours. If, under exceptional circumstances, it has to be used at night or in conditions of reduced visibility, an auxiliary lighting system must be used. Operate in daylight or with artificial lights which guarantee a visibility of at least 100 metres.

1.8 - IMPROPER OR PROHIBITED USES

ATTENTION



In reference to dangerous situations that may occur with the use of the machine and that could cause serious injury to persons or damage to property.

WARNING



This paragraph indicates some of the improper or unauthorised uses; as it is impossible to foresee all possible improper uses, if there are particular occasions of use of the machine not contemplated among those permitted, consult McConnel before carrying out the work.

The following uses must always be strictly avoided:

- Use of the machine by minors, inexperienced, untrained or unlicensed persons;
- Using the machine to lift people or objects;
- Using the flail mower head as a piledriver;
- Using the machine to tow damaged vehicles;
- It must not be used on surfaces contaminated by glass, loose stones, pieces of iron or other extraneous bodies that could be kicked up by the blades of the tool;
- Lifting or pulling tilted loads;
- Placing accessories or equipment classified as dangerous due to their chemical or physical properties (e.g. flammable, toxic, explosive materials etc.) on the machine;
- Overloading the machine beyond its permitted limits;
- Increasing the working length with booms without the authorisation of McConnel;
- Using the machine with equipment not authorised by McConnel;
- Making changes to the machine (hydraulic, electrical or mechanical);
- The machine must not be used on public roads.

Range of action means an area that should be free of people, as it could be hazardous. To this end, also consider what is indicated in the manuals of the individual pieces of equipment and the different operating modes used.

DANGER



If the machine is used in the ways specified above, there will be the risk of overturning or structural breakage of the same, with the consequent risk of injury or death of the operator.

1.9 - RUNNING-IN AND TESTING THE MACHINE

Each machine is carefully adjusted and tested before delivery.

A new machine must however be used with caution for the first 100 hours for the purpose of the efficient running-in of the various components.

If the machine is subjected to an excessive workload during the initial phase of operation, its potential performance will be prematurely compromised and its functionality reduced in a short period of time.

During the running-in period, pay close attention to the following points:

- After start-up, let the engine run at a low speed for 5-6 minutes;
- Avoid running the machine at the maximum speed for the first 100 hours of operation. Avoid sudden accelerations or decelerations.

Refer to the service booklet attached for the various types of maintenance to be carried out. Also refer to the engine manual and to the equipment manual for any type of work that has to be carried out.

ATTENTION

When replacing oil and diesel filters, inspect them internally to check if there are any deposits. If there are, check for possible causes before restarting the machine.


2 - MACHINE SPECIFICATIONS

2.1 - MACHINE DESCRIPTION

Multi-purpose operating machine, specific for grass mowing, shrubs, grass maintenance of roadsides, embankments, etc.

Equipped with hydraulic attachments with quick screw couplings which allow the replacement of various equipment depending on the operational needs.

The machine has a multi-purpose lifter that allows all the equipment allowed by McConnel to be connected.



PERMITTED EQUIPMENT

All the equipment validated by McConnel and listed here, does not alter the stability of the vehicle, including the equipment, up to the permitted gradient (both for equipment with and without ballast).

McConnel declines all responsibility for damage of any kind caused by improper use or use other than that described above.

The approved equipment enables the machine to remain stable at the maximum permitted gradients.

Cutting head	FLAIL HEAD 1300; FLAIL HEAD 1600
Mower bar	CUTTER BAR
Lawnmower plate	ROTARY MOWER
Chain conveyor	TRENCHER
Rotary harrow	ROTARY HARROW
Ground tiller	ROTARY TILLER
Rake	RAKE
Land blade	LAND BLADE
Snow blade	SNOW BLADE
Winch	WINCH

The **ballast weights should be applied when using the following equipment:**

Forestry Head (swivel bats)	FORESTRY HEAD
Forestry head (fixed teeth)	
Bio-shredder	BIO-SHREDDER;
Front loader bucket	FRONT LOADER BUCKET;
High tipping bucket	BUCKET
Forks	FORKS
Grapple bucket	GRAPPLE BUCKET
Snowblower	SNOW BLOWER
Tree shaker	TREE SHAKER
Forestry winch	FORESTRY WINCH

2.2 - RULES APPLIED

This machine has been designed and built in compliance with EC directives on safety and the approximation of the laws of the Member States;
Specifically, the Machinery Directive 2006/42/EC, where applicable and S.I. 2008 No. 1597.

The following standards were also taken into account during the design phase:

- UNI EN ISO 12100:2010 "Safety of machinery" (terminology);
- EN 60204-1:2016 "Safety of machinery" (Electrical equipment);
- 2014/30/EU Electromagnetic compatibility;

The following harmonised standards were used for updating the machine:



- ISO 12100:2010
- EN ISO 4254-1:2015
- EN ISO 4254-12:2018

As well as the following technical specifications:

- UNI EN ISO 3767-1:2016;
- ISO 11684:1995;

2.3 - MACHINE IDENTIFICATION

The machine's identification plate is fixed to the left or right-hand side of the chassis, on the outside of the side member.




WARNING



The serial number and year of manufacture must always be indicated in assistance requests and spare parts orders.

2.3.1 - MACHINE DIRECTIONS

Left or right means with respect to the forward direction of movement.




2.4 - NOISE LEVEL

LpA = This value indicates the maximum sound level perceived by the operator calculated by making a worst case assessment at the 4 points around the machine being tested.

LWA = This value indicates the sound level outside the machine and refers to the noise perceived by those who are in the vicinity of the work area.

Standards:

- S.I. 2008 No. 1597



Moreover, the **LpA** values have been taken at greater distances, resulting in 89 dB(A) at five metres and 80 dB(A) at thirty metres.

ATTENTION



ALWAYS WEAR PROTECTIVE EARMUFFS AS THE MEASURED NOISE VALUES REQUIRE NOISE PROTECTION DEVICES TO BE USED.



3 - SAFETY REQUIREMENTS

3.1 - GENERAL SAFETY RULES

ATTENTION



- Stickers are applied to the machine to ensure safer use. They must be replaced if they are no longer legible.
- The operator must never be an occasional worker but must have some experience with this type of machine.
- If the direct view of the work area from the driving position is not sufficient, the operator must be assisted by an expressly appointed person.
- Check the condition and operation of any part subject to wear on a monthly basis: (pins, valves, piping etc.). Where necessary, replace them with original parts.
- Never, under any circumstances, tamper with the hydraulic system and in any case do not remove the seal from the valves as this would invalidate the warranty. To adjust the valves, contact an authorised workshop.
- Excessive heating of the oil causes damage to the gaskets of the hydraulic circuit and deterioration of the fluid itself. Heating is caused by lamination of the oil through the maximum pressure valve. For this reason, avoid extended operation with the jacks at the end of the stroke.
- It is also necessary to check that the machine emergency button and remote control stop button are working correctly. If the emergency or stop buttons are damaged, the machine must not be started up or its operation must be stopped immediately.
- The machine user is responsible for all property damage or personal injuries caused by machine operation.
- Maintenance, cleaning, adjustments or similar operations on any part of the machine or interchangeable equipment connected to it are strictly forbidden when the machine is moving. Any maintenance, cleaning or adjustments must always be performed with the engine off.
- It is forbidden to remove or alter the guards protecting moving parts or hot surfaces of the machine, or interchangeable equipment connected to it.

3.1.1 - GETTING TO KNOW THE MACHINE THOROUGHLY

The machine must be used only by qualified personnel, who must be familiar with the location and the function of all its controls, tools, indicators, indicator lights and plates.

3.1.2 - WEAR PROTECTIVE CLOTHING

Wear tight fitting clothing and use personal protective equipment in accordance with current regulations. In particular, they are required to wear:

- Noise protection headphones;
- Safety footwear;
- Overalls;
- Work gloves.

During use, the machine may produce dust emissions. If working with dry products (straw or stretches of bare earth) it is advisable to use protective devices such as:

- Eye protection goggles;
- Respiratory dust masks.



3.1.3 - USE SAFETY EQUIPMENT

- A first aid kit should be on hand when the machine is in use;
- A powder type fire extinguisher should be on hand when the machine is in use so that you can take action quickly in case of an emergency;
- Always make sure that the extinguisher is full;
- Use the extinguisher according to current regulations;
- Be prepared to fight a fire and / or handle an emergency;
- Have the numbers of emergency services at hand:
 - Doctors;
 - Ambulances;
 - Hospital;
 - Fire fighters.




WARNING



- The owner of the machine and/or employer is responsible for providing a fire extinguisher and a first aid kit and for periodically making sure that they are in good order.
- A CO₂ fire extinguisher is specific for extinguishing fires of an electrical nature. We recommend using a powder fire extinguisher on the machine in general.

3.1.4 - WARNINGS FOR CHECKS AND MAINTENANCE



Apply a "DO NOT START THE ENGINE" sign to the machine. Remove the keys from the ignition before carrying out checks or maintenance work and delimit the area (for example with road cones).

3.1.5 - CHECKING THE MACHINE

- Carefully inspect the machine every day before use, following the check-list given in this manual.
- Start the engine only in well ventilated areas and make sure that there are no people within the operating range of the machine.
- Covers and safety elements must not be removed. They are designed and built for your safety.
- Do not use the machine if the protective devices or covers are damaged or missing.
- After cleaning or repair the protective devices must be reapplied immediately.
- Keep the machine and all its accessories clean and in good working order at all times.
- It is strictly forbidden to make changes to the machine without prior authorisation from the manufacturer. Changes to the machine can in fact cause hazards and injuries. If these instructions are not observed, the manufacturer assumes no responsibility for the machine.
- Only refuel when the machine is switched off, if possible before having turned it on, and when the fuel tank is cold. If you need to refuel whilst work is in progress, do not add fuel to the tank if the tank is hot or if the engine is still warm. Allow the machine to cool down.

Range of action means an area that should be free of people, as it could be hazardous. To this end, also consider what is indicated in the manuals of the individual pieces of equipment and the different operating modes used.

DANGER



DANGER OF EXPLOSION OR FIRE

During normal daily maintenance do not clean with high pressure water (pressure washer) electrical components, such as:

- Receiver unit and remote control;
- Fuse box and relays;
- Engine control unit and the machine ECUs;

Apply a guard or cover with appropriate means before washing so as to isolate the electrical components.

3.2 - GENERAL PRECAUTIONS

- It is mandatory to read and follow the instructions indicated in the use and maintenance manual before performing any operation or manoeuvre with the machine. It is too late to do so while working. Improper use or an incorrect manoeuvre can result in serious damage to people or property;
- The operators and maintenance technicians must be familiar with the machine, in particular they must know the dangers deriving from incorrect use or incorrect repairs;
- Before starting, carry out all the checks on the machine and equipment such as:
 - Operation;
 - Accident prevention regulations;
 - Guards;
- Even when using the machine correctly, stones or other objects can be projected far away. Therefore, there must be nobody within the danger zone (100 metres). Be very careful when working near roads or buildings;
- Before starting the work, always check the integrity of the tools and of all guards; if damaged or missing, replace them;
- Make sure that nobody can involuntarily start the machine during checks and repairs.
- Do not wear loose clothing;
- Never transport anyone on the machine;
- Never carry persons on the cutting head or on any other mounted equipment;
- Do not stand near the machine until the equipment is at completed standstill;
- Before each start-up, make sure that there are no people and/or animals nearby;
- Before leaving the machine, proceed as follows:
 - Park the machine on a flat surface.
 - Reduce the rpm of the engine before turning it off. Press the remote control red button and turn the ignition key to the "O" position.
 - Remove the ignition key and take the remote control away with you.
- Immediately replace any lost or worn warning plates or pictograms;
- Never underestimate or ignore safety regulations;
- Go to an authorised workshop if the safety devices are not working.
- Keep the remote control out of the reach of unauthorised personnel and especially children.

3.2.1 - SAFETY WARNINGS

The machine has been designed and built according to the technical requirements in force for operations such as mowing grass, hedges, maintenance of green areas of roadsides, slopes, canals, water drainage, etc. Observe the laws, provisions, requirements, ordinances and directives in force for such machines.

The materials used and the pieces of equipment, as well as the production procedures, quality guarantee and checks meet the highest safety and reliability standards.

Use the machine for the purposes specified in this user manual, operating it with the due diligence and carry out accurate maintenance and revisions as envisaged to obtain the highest performance, continuous operation and ensure a long service life of the machine.

3.2.2 - OPERATIONAL SAFETY

The manufacturer shall not be held responsible in case of malfunction and damage if the machine:

- is used for purposes other than those for which it was intended;
- is not manoeuvred, started and maintained according to the service instructions specified in the following manual;
- is not periodically and constantly placed under maintenance as prescribed or non-original spare parts are used;
- it is modified or its equipment is replaced without the written authorisation of the manufacturer, especially when the efficiency of the safety devices has been reduced or eliminated on purpose;
- it is used outside the permitted temperature range;

3.2.3 - SAFETY WHEN USING GRASS MOWING EQUIPMENT

- Before using the machine, remove from the mowing area all stones, sticks, glass, metal wires, bones, branches and any other objects that could be collected and tossed around by the flail rotor or that could damage the cutting head.
- Avoid obstacles during machine operation. Do not use the machine near steep slopes, unstable terrain or areas in which it could tip over.
- When the machine is being used, be very careful not to let it come into contact with hard objects such as drain covers, manhole covers, curbs, guard rails, railway tracks etc. This could cause the tools to break and they could be projected at very high speed.
- Whenever wire, cables, chains or other objects become caught in the rotor, stop immediately in order to avoid damage or dangerous situations. Stop the rotation of the cutter, switch off the engine and remove the key. After having put on work gloves, reset the rotor with the help of pliers or shears.
- Do not continue to use the machine if there vibrations from the flail and/or forestry head that could cause breakages or serious damage. Ascertain the cause of the problem and eliminate it.
- During operation, pay attention to the electrical cables, especially if you need to pass under them, as you could lose the radio signal. In these cases, the machine immediately deactivates (disconnects) the commands and stops with the engine running at idle speed.
- Before raising/lowering the equipment with the raiser, make sure nobody is within ten meters of the machine.

DANGER



- Do not try to free the rotor by making it turn in the opposite direction.
- Danger of projection of materials.

ATTENTION



If you are using other equipment, refer to the manual of that equipment.


3.2.4 - SAFETY REQUIREMENTS FOR THE HYDRAULIC SYSTEM

- Stop immediately if you notice oil leaks.
- Periodically check the hoses. If they are worn, contact McConnel. Before working on the system, lay the head on the floor (or any other mounted equipment) and turn off the engine.
- Oils and greases must be disposed of according to anti-pollution standards.

WARNING

- **Never search for oil leaks with bare hands or other body parts; use paper or cloths to locate the leak.**
 - **Always wear waterproof gloves and eye protection.**
 - **Wait until the oil has cooled before intervening.**
 - **Discharge the oil pressure before disconnecting the hoses or when performing maintenance on the system.**
 - **High pressure oil may penetrate the skin and cause serious infections; in such case seek medical attention immediately.**
 - **These interventions must be performed by authorised personnel.**
-

3.2.5 - LOCATION OF THE SAFETY SIGNS




3.2.6 - DESCRIPTION OF THE SAFETY SIGNS

WARNING




Ensure the good condition of the safety pictograms. If the plates are damaged, they must be replaced with original plates that can be requested from McConnell and placed in the position indicated in the manual. Make sure that the safety pictograms are legible. Clean them using a damp cloth with soap and water.

Hydraulic oil tank



Fuel tank



Hazards associated with the battery

- Keep sparks, lighted matches, and open flames away. Battery gases are explosive.
- Never check the battery charge by connecting the two poles with a metal object. Use an acidimeter or a voltmeter.
- Do not charge a frozen battery: danger of explosion! Warm the battery first to 16°C.
- Danger of electric discharge.
- Corrosion danger.


To check it, refer to section 9.8 of this manual.



Lifting points provided for handling the machine



Emergency stop button



Moving parts danger warning signs

Indicates the presence of moving mechanical parts.

Do not lubricate

Indicates that it is strictly forbidden to lubricate moving parts and that the engine must be switched off.



Hot parts warning sign


Indicates the presence of hot parts such as exhaust pipes or bonnets. Do not touch the areas around the sign.



Personal protective equipment (PPE)

All operators and personnel should be provided with appropriate PPE. In particular, they are required to wear:

- Noise protection earmuffs;
- Safety footwear;
- Overalls;
- Dust mask;
- Protective eyewear;
- Work gloves;




Lubrication zone sign

Indicates the greasing and lubrication points (and possibly the frequency).



Lubrication zone sign

Indicates the greasing point for tensioning the track.



3.2.7 - PRECAUTIONS REGARDING THE EQUIPMENT

- When optional equipment is installed and used, carefully read the relative manual and strictly follow the instructions contained in it.
- Do not use optional or special equipment without having received written approval from McConnell.
- Assembly and use of equipment not authorised by McConnell can compromise safety and cause damage both for the operation and for the duration of the machine.
- Any damage, accident or reduction of efficiency of the machine due to the application and use of unauthorised equipment, does not make McConnell liable.

3.3 - GENERAL SAFETY RULES

3.3.1 - CARE AND MAINTENANCE

The cause of much damage and many accidents can be attributed to mistakes or insufficient maintenance, such as:

- Lack of oil, grease and anti-freeze,
- Lack of cleaning,
- Lack of hydraulic system maintenance (damaged hoses, loose fittings etc.).
- Carry out maintenance works carefully as they are also important for your own safety.
- Never put off repairs.
- Have only specialised or authorised personnel carry out repairs.
- Always observe the following safety requirements, even when you are fully familiar with all the controls:
 - Adapt the speed to the conditions of the travel path.
 - Before beginning work, check that all the movements of the protective devices are functioning properly.
 - Make sure that the emergency stop devices are working correctly (located on the remote control and on the machine).
 - Continuously make sure that no people are in the danger zone of the machine (greater than 100 meters.) Shout an alert, sound your horn to warn people and stop work if these people do not leave the danger area.
 - Do not allow anyone to climb onto the machine.
 - Do not use the machine to lift persons.
 - Never leave the machine when it is switched on.
 - If for some reason, the rotor of the equipment begins to shake, stop the equipment immediately and try to understand the reason and / or restore correct operation. McConnell declines all liability for injury to people or damage to property if the operator fails to comply with these instructions.
 - Clean the machine after use. Do not use petrol or solvent-based products to clean the machine.
 - During operation, and in particular in windy conditions, the user must carefully choose his position in order not to be exposed to exhaust gases, dust or mown grass.
 - Do not operate the equipment if you are unable to see it (behind ridges, round corners of buildings, in tall grass etc...).

ATTENTION



- **Due to vibrations, regularly check that all screw connections are firmly tightened.**
- **This check must be carried for the first time after eight hours of operation and repeated at least weekly.**

ATTENTION



- Do not clean electrical parts (for example the fuse box, actuator and control units) with high pressure water.
- Cover electrical parts with a plastic bag to protect them during washing.

3.3.2 - SAFETY DURING REFUELLING AND TOPPING UP

- Fuel, oil and some type of anti-freeze are highly flammable.
- Keep away from naked flames.
- Turn off the engine and do not smoke when fuelling up.
- Fuel up only when the engine is off and in a well-ventilated area.
- Do not let unauthorised persons come near.
- During filling, hold the fuel pump pistol or the jerry can and keep them always touching the fuel filler hole until the filling operation is over to avoid sparks due to static electricity.
- When filling up is complete, tighten the safety device.
- Do not fill the tank completely. Leave some space in order for the fuel to expand.
- immediately dry off any fuel that may have spilled out.



3.4 - MAINTENANCE PRECAUTIONS

3.4.1 - WARNING SIGNS

Before performing any maintenance operation, place the machine on solid and level ground, lay the equipment on the ground and stop the engine. If other people start the engine and use the control levers while maintenance is being performed, there is a risk of serious injuries or death. To avoid these dangers, before carrying out the maintenance, put the remote control in a safe position, remove its battery and hang the warning signs on the machine.

3.4.2 - TOOLS

Use only tools indicated by the machine manufacturer to prevent personal injuries, discard worn, damaged, low quality or makeshift tools.

ATTENTION



Tools that are not indicated or modified without authorisation will void the warranty and release the manufacturer from any liability for injury to people or damage to property.

3.4.3 - PERSONNEL

The routine maintenance indicated in the manual must be carried out exclusively by authorised and trained personnel. To perform maintenance on or service components not specified in this manual, please contact McConnel.

3.4.4 - WORKING UNDER THE MACHINE

If it is necessary to carry out maintenance under the machine, make sure that you have all the suitable tools to do so. Lift the machine through the appropriate hooks on the carriage, with suitable ropes or chains (see "**7.2 Lifting the machine**").
Place the machine on suitable supports in a horizontal position.

DANGER



- **Do not climb on or get under the machine when it is raised and not properly supported as indicated in the safety standards.**
- **Make sure that you use cables, chains and lifting means appropriate for the load and for the lifting of objects.**

3.4.5 - KEEPING THE MACHINE CLEAN

The routine maintenance indicated in the manual must be carried out exclusively by authorised and trained personnel. To perform maintenance on or service components not specified in this manual, please contact McConnel.

- **Regularly remove all flammable materials (dry grass and leaves) from the area around the exhaust pipe, engine, battery and all the points in which they can come into contact with oil or fuel and therefore ignite.**
- Clean the machine after use.
- Do not use petrol or solvent-based products to clean the machine. **Do not clean electrical parts with water under pressure.**

3.4.6 - PERIODICAL REPLACEMENT OF THE MAIN SAFETY COMPONENTS

Periodically check the following components, important for fire prevention:

- Supply system: fuel delivery and return pipes;
- Hydraulic system: main delivery pipes of the hydraulic motors;
- Hydraulic system: pipes for utilities from the control valve to the hydraulic cylinders.

Carefully check the state of efficiency and cleanliness of the quick coupling devices supplied with the machine.

Even if they appear to be in a good state, these components have to be replaced periodically with new pieces. Over time, these components in fact tend to deteriorate. In the case that one of these parts is defective, replace or repair it even if it is still not past its expiry date.

3.4.7 - HYDRAULIC SYSTEM

When the machine's engine is switched off, there may be a residual pressure of 2 bar on all its hydraulic systems.



In order to discharge this pressure from the systems for carrying out maintenance, proceed as follows:

1. Lower the lifting device completely;
2. If the cutting head is attached, close the guard;
3. Make sure that the engine has been switched off and that the mechanisms are stationary.
4. Loosen the fittings of the lifter cylinders;
5. Loosen the fittings of the guard-opening cylinder;
6. Loosen the fittings of the drainage lines of the translation and cutting head motors;
7. As regards the control valve, the pressure equalizes with that of the tank;

4 - TECHNICAL DATA

4.1 - TECHNICAL SPECIFICATIONS

DIMENSIONS



^(a) with 250 mm (10") track;

^(b) with 280 mm (11") track;

WEIGHT

The total weight of the Robocut T500 machine, without equipment is 1200 kg.

DRIVES

Supplier	PERKINS	Type	403J-E17T
No. of cylinders	3	Engine displacement	1662 cc
Power @ 2800 rpm	36 kW / 50 HP	Peak torque @ 1600 rpm	166 Nm
Cooling	Liquid	Air filter	Dry
Exhaust gas standard	USA	EPA Final Tier 4	
	EU	Stage V	

ELECTRICAL SYSTEM

Operating voltage: 12 VDC
 Alternator: 85 A
 Battery: 2 x 18 Ah

HYDRAULIC SYSTEM

Circuit	Pump type	Qty	Maximum capacity	
			L/min	Bar
Travel	Tandem variable displacement piston pump in closed circuit	2	28 each	250
PTO	Variable displacement pistons type in closed circuit	1	56	300
Services	Gear pump	1	14	190

TRANSFER SPEED

Speed	Forward		Reverse	
	1 (Slow)	2 (Fast)	1 (Slow)	2 (Fast)
Km/h	0 - 4	0 - 7	0 - 4	0 - 7
MPH	0 - 2.50	0 - 4.35	0 - 2.50	0 - 4.35

TRACKS

Type	Width (mm)	Cup weight/single track (kg)
Rubber	250 x 72 x 47	94 / 47
Rubber	280 x 72 x 47	158 / 79
Rubber with iron cleats and studs	250 x 72 x 47	200 / 100

CAPACITIES TABLE

	Quantity
Engine oil	7,5 L
Diesel tank capacity	21 L
Hydraulic oil tank capacity	11 L
Coolant	7 L

RADIO CONTROL

Transmission frequency (EU)	863 - 870 MHz
RF POWER is	<25 mW ERP
Transmission frequency (US)	915 - 928 MHz
RF POWER is	<50 mW ERP
The operating radius of the radio control is	150 metres

WARNING




It is recommended that the machine be visually monitored at all times so do not operate it at a distance greater than 50 - 80 metres.

TRANSMITTER BATTERY

Characteristics	Type	7.2 V
	Voltage	750 mAh
	Capacity	Ni-MH
Average battery time ^(*) :		11 hours
Battery charge time:		4 hours


^(*) Depending on how many operations are carried out using the radio control.

4.2 - MACHINE NAME



Pos.	Description
1	Front bonnet
2	Left engine bonnet
3	Left Track
4	Hydraulic oil tank
5	Fuel tank

Pos.	Description
6	Right engine bonnet
7	Right drive wheel
8	Lifting device
9	Right track



Pos.	Description
10	Ignition key
11	Display
12	Left drive wheel

Pos.	Description
13	Radiator casing
14	Air filter
15	Radiator

5 - TERMINOLOGY

5.1 - DEFINITION OF TERMS USED

OPERATOR

Personnel trained to operate the machine in work conditions and while travelling and trained to carry out ordinary checks and clean the machine.

Must not have disabilities of any kind or health problems.

SPECIALISED OR MAINTENANCE PERSONNEL

Personnel trained to carry out extraordinary maintenance operations, assembly, disassembly and reassembly of machine components.

Must not have disabilities of any kind or health problems.

AUTHORISED PERSONNEL

Personnel trained to carry out extraordinary maintenance operations, assembly, disassembly and reassembly of machine components.

Must be authorised in writing by the company McConnel to intervene on the machine.

Must not have disabilities of any kind or health problems.

OPERATOR ASSISTANT

Personnel trained to help the operator in any manoeuvre of the machine (manoeuvre at the construction site with reduced visibility, loading and unloading from the means of transport, use of the manual pump, etc.) and during the activities at the mobile construction site (cutting on public roads).

Must know the main work safety requirements.

AUTHORISED WORKSHOP

Authorised repair workshop with personnel trained to carry out extraordinary maintenance operations, assembly, disassembly and reassembly of machine components.

Must be authorised in writing by the company McConnel to intervene on the machine.

The operator is asked to refer to standard UNI EN 12100-2010, for the definition of the other terms in this manual.

6 - USE OF THE MACHINE

6.1 - PRELIMINARY CHECKS

The operator must verify that the machine is supplied with:

- Machine and equipment user manual;
- Check/service booklet;
- Heat engine manual;
- Technical annexes;

If the machine is resold as a “second hand” machine, the customer / user must provide the purchaser with the complete use and maintenance manual as well as the inspection log book.

6.2 - CHECKS TO BE PERFORMED AT THE START OF EACH WORKING DAY

- Carry out an external inspection of the machine (joints, hoses, hydraulic components, etc.) and check for any leaks of oil or other liquids.
- Check the rubber hoses of the machine and make sure there are no cuts, holes, scratches, leakages, etc.

WARNING



Never search for oil leaks with bare hands or other body parts; use paper or cloths to locate the leak. Always wear waterproof gloves and eye protection.



6.3 - CHECKING THE CHROME-PLATED PARTS

Carry out an inspection of the chrome-plated parts of the machine (jacks) and check that they are not scratched or damaged. In the case of damage, replace.

6.4 - RECEIVER UNIT

The radio receiver unit (**A**) is located at the front of the machine. It can only be accessed via the front hood.




WARNING



If you wish to clean the machine with a pressure washer, do not direct the jet towards the radio receiver unit. Cover it with a plastic bag as a precaution.

6.4.1 - RECEIVER UNIT DESCRIPTION



POS.	DESCRIPTION
1	Fastening holes
2	Rating plate
3	Seven segment display
4	LED
5	Machine plate
6	Connectors


6.4.2 - RECEIVER IDENTIFICATION PLATES

The following plates are on the receiver unit:

Position	Plate	Information contained
Receiver unit cover	Radio control unit identification plate	The serial number of the radio control (S/N), a QR code and the year of manufacture.
	Rating plate	The MODEL, TYPE and main technical data of the receiver unit, the markings and any radio control trademarks.

6.4.3 - RECEIVER UNIT LIGHT SIGNALS

There are four seven segment displays in the receiver unit and five LEDS named POWER, STATUS, RUN, ERR and SETUP.



POS.	DESCRIPTION
1	STATUS
2	RUN
3	ERR
4	SETUP
5	POWER

The meaning of the light signals will be described in the following paragraphs.
The possible actions to be taken are indicated in section **“6.19.4C Receiver faults”**.

6.4.4 - SEVEN SEGMENT DISPLAY

The seven segments displays indicate the status of the receiver unit and the radio connection. The seven segments displays also indicate any errors.

SIGNAL	DESCRIPTION
	There is no communication between the transmitter and the receiver.
	The radio control is active.
	Internal temperature of the receiver unit (°C).
	Power supply voltage of the receiver unit (V).

The signals alternate with each other when the radio control is started.

6.4.5 - POWER LED

The POWER LED indicates the status of the receiver and the radio connection.

SIGNAL	DESCRIPTION
LED off	The receiver is off
LED on	There is no communication between the transmitter and the receiver
The LED flashes and then pauses	The radio control is active and transmits at a frequency of 863 - 870 MHz
The LED flashes twice and then pauses	The radio control is active and transmits at a frequency of 915 - 928 MHz
The LED flashes three times and then pauses	The radio control is active and communicates via the radio control cable.

6.4.6 - STATUS LED

The STATUS LED signals the presence of faults in the outputs or power supply and indicates the reception of data from the transmitter.

SIGNAL	DESCRIPTION
LED off	The receiver is off
The LED flashes slowly	There is an overvoltage in the power supply.
The LED flashes rapidly	The receiver receives data from the transmitter.

6.4.7 - RUN LED

The RUN LED indicates the CAN-bus communication status of the receiver.

SIGNAL	DESCRIPTION
LED off	The receiver in the CAN bus network is switched off
The LED flashes	The receiver is not sending commands to the CAN-bus network
LED on	The receiver in the CAN bus network is working correctly

6.4.8 - ERR LED

The ERR LED indicates the CAN-bus communication status.


SIGNAL	DESCRIPTION
LED off	The CAN communication is working properly
The LED flashes	The CAN communication is not working properly
LED on	No CAN communication

6.4.9 - SETUP LED

The SETUP LED indicates the status of the memory card and the code key.

SIGNAL	DESCRIPTION
LED off	There are no errors in the memory card or the code key
The LED flashes once	There is an error in the code key
The LED flashes twice	There is an error in the memory card

6.5 - TRANSMITTER UNIT




TRANSMITTER FUNCTIONS

1	Forward movement/ backward movement joystick
2	Steering / equipment lifting joystick
3	Engine rpm speed increase button
4	Engine rpm speed decrease button
5	Reversible fan start button
6	Float function / lifter suspension function switch
7	Auxiliary service selector
8	Open / close mulching head guard switch
9	Mulching head RPM increase / decrease potentiometer
10	Mulching head clockwise / anti-clockwise rotation switch
11	Slow / fast speed selector
12	Manoeuvre progress reversal selector switch
13	Connect transmitter - receiver button
14	Engine ignition button
15	Engine off button
16	Speed of progress regulation potentiometer
17	Right / left direction corrector potentiometer
18	Emergency button
-	Not used

6.5.1 - TRANSMITTER SPECIFICATIONS

- The transmission frequency for EU member states is 863-870 MHz.
- RF POWER is < 25 mW ERP.
- The operating radius of the radio control is 150 metres. Obviously, it is recommended that you keep the machine in sight at all times so do not operate it at distances greater than 50-80 metres.

6.5.2 - TRANSMITTER DESCRIPTION



POS.	DESCRIPTION
1	Actuators (joystick, selector switches, buttons)
2	Emergency Stop Button
3	LED
4	ENTER button
5	M-KEY (electronic power key)
6	Wired radio control connector
7	Battery

6.5.3 - TRANSMITTER UNIT IDENTIFICATION PLATES




The following plates are present in the transmitter unit.

POS.	PLATE	POSITION	INFORMATION CONTAINED
1	Radio control unit identification plate.	Battery housing	The serial number of the radio control, QR-code and the year of manufacture
2	Transmitter unit identification plate.	Battery housing	The year of manufacture, the QR-code and the identification number of the transmitter unit (TU ID)
3	Rating plate.	Rear of transmitter unit.	The MODEL, TYPE and main technical data of the transmitter unit, the markings and any radio control trademarks.

6.5.4 - TRANSMITTER LIGHT AND AUDIBLE SIGNALS

The transmitter unit features four LEDs.



	Symbol	LED
A		Red
B		Green
C	-	Data feedback

The green LED (B) and the red LED (A) provide information about the radio control.

6.5.5 - GREEN LED

The meaning of the signals provided by the green LED (B), when the red LED (A) is off, are described in the following table.

GREEN LED	
SIGNAL	DESCRIPTION
• Green LED off • Red LED off	The transmitter is off
• Green LED flashes rapidly • Red LED off	There is no communication between the transmitter and the receiver
• The green LED flashes and then pauses • Red LED off	The radio control is active and transmits at a frequency of 863 - 870 MHz
• The green LED flashes twice and the pauses • Red LED off	The radio control is active and transmits at a frequency of 915 - 928 MHz
• The green LED flashes three times and the pauses • Red LED off	The radio control is active and communicates via the radio control cable.

6.5.6 - RED LED

The signals given by the red LED (**A**) indicate a malfunction of the radio control. The meanings of these signals and possible actions to be taken are described in the section **"6.19.4A Transmitter faults"**.

6.5.7 - AUDIBLE SIGNALS

The transmitter is fitted with an audible warning device that is activated when:

- the battery is running low;
- the transmitter unit has been on for eight hours;
- the transmitter unit is not working properly;
- the STOP button is pressed or faulty when the radio control is started;
- the SAFETY command is active when the radio control is started;
- an actuator (joystick, switch or button) is active when the radio control is switched on.
- the battery is flat when the radio control is started.

The audible warning device is activated each time the red LED (**A**) lights up. The meaning of the red LED (**A**) turning on, the audible warning device being activated and any action that needs to be taken are described in section **"6.19.4A Transmitter faults"**.

6.5.8 - M-KEY



There is an ignition key in the radio control referred to as the M-KEY. The radio control cannot operate if the ignition M-KEY has not been inserted into the transmitter unit. The M-KEY allows the transmitter unit to be powered.

INSERTING THE M-KEY

Insert the M-KEY into the relative housing.


REMOVING THE M-KEY

Pull the M-KEY via the cord to remove it from its housing.

6.5.9 - TRANSMITTER BATTERY

INSERTING THE BATTERY

- A) Push the battery towards the contacts on the transmitter unit.
- B) Insert it into the slot.



REMOVING THE BATTERY

- C) Push the battery towards the contacts on the transmitter unit.
- D) Pull it out of the slot.



WARNING



Remove the battery, if possible, whenever the transmitter unit is not being used.

6.5.10 - BATTERY LOW

A battery can normally operate for approximately 11 hours. This is obviously an average value. One should also consider how many operations are carried out as this will determine a higher / lower power consumption.

The transmitter unit indicates if the battery is not sufficiently charged (the red LED flashes and an audible alarm is emitted).

The transmitter unit switches off automatically 3.5 minutes after the warning was issued.

WARNING

**Place the machine in a safe condition and replace the battery with one that is charged.
The battery removed should be recharged. It can be charged in approximately 4 hours.**

6.6 - START-UP

ATTENTION

- Before starting up the machine, the information and safety instructions contained in the user manual must be read and understood.
- Professional operators must be instructed and trained.
- Familiarise yourself with the controls before starting operation.

DANGER

- **DO NOT** take drugs or drink alcohol before or while using the machine and tools. The use of drugs and alcohol or being in a non-optimal psycho-physical condition can affect responsiveness and coordination, and therefore, impair the capability to use the equipment safely.
- Before using the machine or equipment, the operator who usually takes medicines must consult a physician as regards the side effects of the drug that might impair the ability to use the equipment safely.
- **NEVER** consciously allow anyone to use the machine when their attention or coordination is compromised.
- This could result in serious injuries or death of the operator or third parties if the operator is under the influence of drugs or alcohol.

6.7 - STARTING THE MACHINE

DANGER

- Observe the safety instructions.
- Start the machine only outdoors, never indoors, otherwise you could be poisoned by exhaust fumes.




DANGER

The engine exhaust contains carbon monoxide, a harmful gas that can kill in minutes. **IT IS INVISIBLE AND HAS NO TASTE OR SMELL.** Even if you do not breathe in exhaust gases, you may still be exposed to carbon monoxide. If you feel sick, with a feeling of discomfort or weakness when using the product, stop the engine and get out into the fresh air **IMMEDIATELY**. Seek medical attention. Carbon monoxide poisoning may have occurred.

WARNING

Before starting the machine, check the fuel level and fuel up if necessary.

6.7.1 - CONNECTING THE MACHINE AND TRANSMITTER



To connect the machine and the transmitter, proceed as follows:


1. Arm the emergency button (A) on the machine by rotating it clockwise.
2. Arm the emergency button (18) on the radio control by rotating it clockwise.
3. Turn the ignition key (B) to position "I" by turning it clockwise by one click. Wait a few seconds for the machine to check the functions.
4. Press the button at the side (13) to search / connect the transmitter and receiver.
5. Once the connection has been established, an audible signal (horn) will be emitted.

WARNING



- If for any reason, the connection signal is lost between the transmitter and receiver of the radio control, the machine stops immediately.
- The connection between the transmitter and receiver has to be re-established in order to continue.

6.7.2 - STARTING THE ENGINE



The machine can be started via the:

- Key in the machine
- Radio control

To start the engine using the key:

1. Turn the ignition key (B) to position "I" by turning it clockwise by one click. Wait a few seconds for the machine to check the functions.
2. Turn the ignition key (B) to position "II" by turning it clockwise by one more click. Release the key once the engine has started.

WARNING



If the engine is started using the key it is no longer possible to connect with the radio control!

ATTENTION






- **The starter motor must only be operated continuously for a maximum of 5 seconds. Trying to start the engine for too long will damage the starter motor.**
- **Wait one minute before attempting to start again.**
- **BURNT OUT STARTER MOTORS ARE NOT COVERED BY THE WARRANTY.**

To start the engine via the radio control, proceed as follows:

1. Connect the machine and the transmitter (see section "6.7.1 *Connecting the machine and transmitter*").
2. Wait a few seconds for the machine to check the functions.
3. Start the engine by pressing the button (14).

6.7.3 - STOPPING THE ENGINE



To stop the engine via the radio control, proceed as follows:

1. Decrease the engine speed.
2. Wait about thirty seconds.
3. Press the button at the side (15) until the engine stops.
4. Press the emergency button (18) to turn off and inhibit the radio control.
5. Switch off the machine by turning the key (B) to "OFF".
6. Press the emergency stop button (A) on the machine.

WARNING



- After stopping the engine, always remember to switch off the machine by turning the ignition key to the "OFF" position. If the key remains in the "ON" position, the electric fuel pump can overheat and draw in air causing it to break. Additionally, if it is left like this for a long time, it uses a large amount of power and damages the batteries.
- **McCONNEL RESERVES THE RIGHT TO REPLACE DAMAGED PARTS ONLY AFTER HAVING EXAMINED THEM.**


6.7.4 - EMERGENCY STOP AND RESETTING THE MACHINE

An emergency stop can be carried out as follows:

- Press the emergency stop button **(A)** on the machine.
 1. All the functions stop, including the engine.
 2. In order to operate the machine again, you have to rearm the emergency button (A) and carry out the procedure for connecting the transmitter to the machine.

- Press the emergency button **(18)** on the radio control:
 3. The engine will continue to run at idle speed and all operational functions will be cancelled.
 4. Switch off the machine by turning the key (B) to "OFF".
 5. In order to operate the machine again:
 - A. Make sure that the cause of the emergency stop has been resolved
 - B. In order to operate the machine again, you have to rearm the emergency button **(18)** and carry out the procedure for connecting the radio control.

6.8 - MOVEMENT CONTROL



6.8.1 - MOVING THE MACHINE FORWARDS AND BACKWARDS

To move the machine forwards or backwards, move the left-hand side joystick (1) forwards or backwards.

This is a proportional control so the more you move the joystick the faster the machine moves. The top speed that can be achieved will be determined by the position of the:

- Left joystick (1).
- The switch (11).
- The potentiometer (16).

6.8.2 - STEERING

The machine is steered by using the right-hand side joystick (2). Move the joystick to the right or left in to steer the machine.

6.8.3 - CONTROLLING THE ENGINE SPEED

Buttons (3) and (4) are used to regulate the engine speed.

- The button (3) increases the engine RPM.
- The button (4) decreases the engine RPM.

6.8.4 - GEAR CHANGE SWITCH

The switch (11) allows you to change gear.

- Switch in the up position: 1st gear (slow).
- Switch in the down position: 2nd gear (fast).

6.8.5 - MACHINE DIRECTION CONTROLS SWAP

The switch (12) allows you to swap the controls for joystick (1).


- When the switch is in the up position, the joystick (1) will operate normally.
- When the switch is in the down position: the controls of the joystick (1) will be inverted.

6.8.6 - SPEED POTENTIOMETER

The potentiometer (16) regulates the maximum speed of the machine from 0 to 100%. The potentiometer setting chosen will depend on the various work conditions that the operator will come across and should always ensure maximum control over the machine.

6.8.7 - STEERING BIAS CONTROL

The potentiometer (17) enables the direction of travel to be compensated when working on steep side slopes. Turn the potentiometer to the right or left to correct the path of the machine.




6.9 - REVERSIBLE FAN

The Robocut T500 is fitted with a reversible fan (A) that allows the radiator and the radiator casing to be cleaned by removing any cutting residues. This keeps the engine cooling system and the hydraulic system working efficiently.

This function is enabled by pressing the button at the side (5). This starts an automatic cycle in which the direction of the fan blades are reversed in order to remove any debris from radiators and protective guards.


It takes approximately fifteen seconds to complete a cleaning cycle.




ATTENTION




- Make sure that there are no people or animals close to the machine or in the direction of the radiator to prevent them being covered with dust.
- Maintain a distance of at least 10 meters from the machine and wear the recommended PPE.



Cooling




Reversing



Cleaning

6.10 - CONTROLLING THE LIFTER



6.10.1 - RAISING AND LOWERING

The height of the equipment attached to the lifter can be adjusted using the right-hand joystick (2).

- Move the joystick forwards to lower the equipment.
- Move the joystick backwards to raise the equipment.


6.10.2 - FLOATING / SUSPENSION FUNCTION

The switch (6) allows you to activate two functions that are specific for the lifter.

- The suspension function, which can be activated by moving the switch downwards.
- The floating function, which can be enabled by pushing the switch upwards.
- Both functions are disabled when the switch is in the central position.

6.10.3 - SUSPENSION

The suspension function, once enabled, allows the lifter to almost completely compensate for the weight of the equipment attached to the machine, in order to allow easier manoeuvres and ensure reduced impact of the tool on the ground.




6.10.4 - FLOATING FUNCTION

Once the float function has been enabled, the equipment applied to the lifter is free to adapt to the unevenness of the ground without hydraulic constraints.

DANGER**CRUSHING HAZARD**

Only activate this function when the equipment is resting on the ground. Otherwise, the equipment may be lowered in an uncontrolled manner.



6.11 - ATTACHING A TOOL

DANGER

- When coupling or uncoupling equipment, stand at the side of the machine away from the equipment (at least one metre away).
- The equipment must be mechanically connected and fixed to the machine before proceeding with the hydraulic connection.
- Hydraulic connections must be made with the engine off.

ATTENTION

- Before making a hydraulic connection between machine and equipment, wipe the quick couplings or the multi-connection plates of both parts with a cloth; this prevents the hydraulic oil becoming contaminated with foreign matter.
- Firmly tighten the screw-on hydraulic couplings after hitching the equipment.
- Failure to tighten the quick couplings (even partially) can cause the hydraulic motor of the tool to break and / or the oil seal to be ejected.

ATTENTION


- Read and follow the instructions provided to ensure safety during the use of the equipment moved by the PTO.
- Comply with the indications provided by the equipment manufacturer.
- Use the safety devices prescribed and make sure that they are in good condition.
- Make sure that the equipment is correctly connected and that it does not hit other parts of the machine when raised.
- In some cases, changing the equipment can alter the overall centre of gravity and affect the stability of the machine. Contact McConnel for adding special ballast to restore the machine's centre of gravity.

ATTENTION


- In some cases, the tool change causes the overall centre of gravity to shift which could make the machine unstable. Contact McConnel about adding ballast to correct the machine's centre of gravity.

The machine is fitted with a lifting device on which the various approved tools can be attached. To do this, follow the steps below:


1. Start the diesel engine and connect with the remote control (6.7.1 *Connecting the machine and transmitter*);
2. Lower the lifting device as far as possible using the right-hand joystick (2);




3. Slowly move the T500 until it is close to the mounting plate of the tool that was previously placed in front of the machine;




4. Using the right-hand joystick (2), raise the lifting device to attach the equipment;
5. Secure the tool with six M12 x 40 bolts to the machine support using an 18-mm spanner;
6. Turn off the engine;




7. Connect the hydraulic power lines of the tool to the quick couplings on the right-hand side of the machine; taking care to clean them before making the connection. The outermost coupling is for the drainage line, while the inner two are for lines (A) and (B).



8. Connect the hydraulic service pipes (of the tool) to the machine's quick couplings on the right-hand side, taking care to clean them before making the connection.
- The outermost couplings are used for the auxiliary function (AUX 1).
 - The innermost couplings are used for the auxiliary function (AUX 2).



6.12 - EQUIPMENT CONTROLS



6.12.1 - ACTIVATING / DEACTIVATING THE PTO

The PTO is controlled by the switch (10):

- When the switch is in the central position, the PTO is (OFF).
- When the switch is in the up position, the PTO is activated and rotates anti-clockwise.
- When the switch is in the down position, the PTO is activated and rotates clockwise.

6.12.2 - INCREASING / DECREASING THE PTO SPEED

Once the PTO has been activated, its speed of rotation can be controlled using the potentiometer (9). When the potentiometer is at 0% the equipment is stationary. Gradually rotate the potentiometer (9) clockwise to 100% to reach the maximum RPM.

Rotate the potentiometer (9) anticlockwise to decrease the PTO speed.


The maximum RPM that the PTO can reach is determined by the position of the potentiometer (9) and the engine speed.

6.12.3 - AUXILIARY SERVICES AUX 1

Auxiliary service AUX 1 is controlled by the switch (7). This switch has two unstable positions (the outer positions are not fixed, they return automatically to the central position). Auxiliary service AUX 1 is also replicated at the rear left of the machine.

Switch (7), auxiliary services AUX 1:

- When the switch (7) is in the central position no signal is transmitted.
- When the switch is in the up position, it has an effect on AUX 1.
- When the switch is in the down position, it has the opposite effect to the previous one on AUX 1.



6.12.4 - AUXILIARY SERVICES AUX 2

Auxiliary service AUX 2 is controlled by the switch (8) (it usually opens or closes the head guard during maintenance). This switch has two unstable positions (the outer positions are not fixed, they return automatically to the central position).

Switch (8), auxiliary services AUX 2:


- When the switch (8) is in the central position no signal is transmitted.
- When the switch is in the up position, it activates an effect on AUX 2 (or opens the mulching head guard).
- When the switch is in the down position, it has the opposite effect to the previous one on AUX 2 (or it closes the mulching head guard).

6.12.5 - REAR AUXILIARY SERVICES AUX 3

Auxiliary service AUX 3 is controlled by the button (14) and the switch (7). This switch has two unstable positions (the outer positions are not fixed, they return automatically to the central position).

Press the button (14) and move the switch (7) as follows:

- When the switch (7) is in the central position no signal is transmitted.
- When the switch is in the up position, it has an effect on AUX 3.
- When the switch is in the down position, it has the opposite effect to the previous one on AUX 3.



6.12.6 - STARTING, CONTROLLING AND STOPPING THE MULCHING HEAD

The following procedure assumes that the equipment has been correctly connected to the machine, both mechanically and hydraulically. To activate the equipment, proceed as follows:

1. Switch on the machine's engine.
2. Use the switch (10) to activate the PTO, selecting the cutting direction of the rotor.
3. To start the rotor, turn the potentiometer (9). When the rotor starts to rotate, increase its speed of rotation by turning the potentiometer clockwise to 100%.
4. You can now use the button (3) to increase the speed of the engine to the required working speed.
5. Rotor speed during operation (engine running at maximum speed):

ROBO-FLAILHEAD	3000 - 3200 rpm
ROBO-FOREST	2430 ÷ 2500 rpm

Switch (8) opens and closes the head guard:

- When the switch is in the up position, the guard opens.
- When the switch is in the down position, the guard closes.

To stop the equipment:


- Reduce the engine speed using the button (4).
- Reduce the speed of the rotor by turning the potentiometer (9) anticlockwise.
- Move the switch (10) to the central position to deactivate the PTO.

ATTENTION




If you use equipment other than a head, refer to its use and maintenance manual as this equipment may have a different use.

6.13 - CONTROL PANEL




POS.	DESCRIPTION
A	Ignition panel
B	Display

6.13.1 - LCD DISPLAY



POS.	DESCRIPTION
A	Engine rpm
B	Coolant temperature
C	Fuel level
D	Warning light/fault area
1	PAGE UP button
2	PAGE DOWN button
3	ENTER button
4	HOME button
5	---



6.13.2 - WARNING LIGHTS

The following indicator lights/warnings may appear on the display according to the faults that may arise.


	Acoustic signal	Stop engine	Cause	Solution
	YES	NO	Fuel tank less than 1/4 full	Top up
	NO	NO	The parking brake is on	Move the left-hand side joystick forwards/backwards
	YES	NO	Hydraulic oil level less than 2/3	Top up and/or check for leaks
	NO	YES	Oil level too low	Top up and/or check for leaks
	NO	YES	The hydraulic oil filter is clogged	Replace the cartridge
	NO	NO	The alternator does not charge the battery	Check the alternator and/or contact customer care
	NO	YES	The air filter is clogged	Clean the filter elements
	NO	NO	Active candle pre-heating	Wait for the indicator light to turn off and start the machine
	NO	YES	Engine oil pressure too low	Check the engine oil level and/or the engine oil sensor
	YES	NO	ECU detects engine failure	Stop the heat engine immediately, see the alarm screen and contact McConnel Support Service.
	YES	YES	ECU detects serious engine failure	Refer to the alarms screen and contact McConnel Support Service.
	NO	YES	Coolant temperature > 110°C	Clean the radiator and/or check the level of coolant
	YES	NO	Indicates that the anti-pollution system is not working or has been tampered with	Contact McConnel Support Service.
	NO	NO	DPF cleaning in progress	Wait for the completion of regeneration

	Acoustic signal	Stop engine	Cause	Solution
	NO	NO	DPF regeneration request	Proceed with the stationary regeneration
	NO	NO	Connection with the lost transmitter	Make a new connection or Contact McConnell Support Service.
	NO	NO	2nd level regeneration request The ECU detects an error in the engine	Refer to the alarms screen and contact McConnell Support Service.
	YES	YES	The ECU detects a serious error in the engine	Refer to the alarms screen and contact McConnell Support Service.
	NO	NO	DPF regeneration go-ahead	Wait for the completion of regeneration
	NO	NO	DPF regeneration inhibited	Carry out a regeneration

WARNING


Once the machine is powered, via the starter panel, causing the initial check of the heat engine control unit (ECU), it is possible that all warning lights will be displayed.

6.13.3 - MACHINE HOURS COUNTER / MAINTENANCE SCREEN




- The display shows the machine hours (1) and the scheduled servicing times (2).
- See the Maintenance section when the scheduled number of hours has been reached.
- The servicing indicator light (3) appears when the scheduled maintenance times have been reached. Press the PAGE UP or DOWN key to view the counter and scheduled servicing.
- For servicing, indicated in the specific manual, contact your local authorised service centre.

ATTENTION



The Service indicator light will flash every time the engine is started until the release code is entered (once the machine has been serviced).

MAINTENANCE CODE



Every 50 hours, the machine prompts you to inspect it, after which the maintenance error has to be reset.

1. When the servicing has been completed, enter the four-digit numeric code (four digits) supplied at the time of purchase or contract McConnel's support service. The code in this case is 6094.
2. To view the page, press the ENTER button for 3 seconds.
3. Enter the code by moving from left to right with the HOME key.
4. Confirm the operation by pressing the ENTER key.

ATTENTION



Entering the code without having carried out the required service will invalidate the McConnel warranty.


6.13.4 - ALARM SCREENS

ATTENTION




In the presence of these screens, we recommend transcribing the codes displayed and contacting the McConnel Support Service for more information.

ENGINE SCREENS



In case of faults and/or malfunctions related to the heat engine, the engine alarm screen will be automatically displayed in the display. This screen will display two diagnostic codes the SPN error and the FMI error and will both be flanked by a number. The SPN number identifies the system or component that has the problem; while the IMF identifies the type of problem that has occurred. The combination of the two identifies the type of error.

MACHINE ALARMS




In case of faults and/or malfunctions related to the machine, alarm codes will be automatically displayed on the display followed by a number. The combination of the two alarms identifies the type of error.

ATTENTION




Contact McConnel's support service for further information.

6.13.5 - FLATNESS SENSOR (OPTIONAL)



As an option, a flatness sensor can be installed in the machine. In the event that the latter is installed in the machine, the relative screen will be present.

6.13.6 - CHANGE OPERATION MODE SCREEN (OPTIONAL)




In the Robocut T500 you can optionally set three different working modes according to the type of activity required.

It is possible to access the menu in the following way:

- Scrolling in the menu with the UP and DOWN arrows to the screen (A);
- Enter the numeric code (**1234**) supplied at the time of purchase or contact McConnel's support service, then press ENTER;
- This accesses the screen (B) in which it will be possible to select modes (1), (2) or (3) using the UP and DOWN buttons; press ENTER to confirm the mode required.

6.13.7 - REGENERATION SCREEN



	Symbol
1	DPF cleaning in progress
2	DPF regeneration request
3	Engine warning
4	Stop engine
5	DPF regeneration go-ahead
6	DPF regeneration inhibited

NOTE: On the diagnostic screen you will never see all the lights lit at the same time, as shown above. The figure is only used to illustrate the warning lights that may appear during use.

1. DPF CLEANING IN PROGRESS:

- Appears during regeneration;
- Disappears when regeneration is finished;

2. DPF REGENERATION:

- It appears when the ECU (heat engine control unit) determines that a regeneration is necessary. Press the consent button to start the regeneration.
- The indicator light disappears when regeneration begins;

3. ENGINE WARNING:

- Appears when thermal engine errors are detected. Contact McConnel Support Service;
- Flashes when regeneration is necessary;

4. STOP ENGINE:

- It appears when serious thermal engine failures are detected. Immediately stop the heat engine and contact the McConnel Support Service;

5. DPF REGENERATION CONSENT:

- Appears when the regeneration consent button is pressed. It remains present during regeneration.
- Disappears when regeneration is finished;

6. DPF REGENERATION INHIBITED:

- Appears when the inhibit regeneration button is pressed.

6.14 - FUSES AND RELAYS

ATTENTION




- Before replacing a fuse, make sure that you have removed the ignition key.
- If the fuses are oxidised, corroded or are not perfectly retained in place, only replace with fuses of the same capacity.
- If the engine does not turn when the starter switch is moved to the ignition position, check the main fuse and replace it if necessary.

Most of the fuses and relays are located inside the boxes (A) and (B), located in the front of the machine: if necessary raise the front bonnet and intervene by replacing the fuses or relays.




6.14.1 - QPL - FUSES AND RELAYS



FUSES		
Position	A	Function
F1	10	Remote control
F2	-	-
F3	15	Engine control unit
F4	-	-
F5	20	Work headlights
F6	-	-
F7	10	Horn
F8	-	-
F9	-	-
F10	-	-
F11	10	+15 Telematics
F12	5	+30 Telematics
F13	10	12V socket
F14	7.5	Ignition panel
F15	5	Alternator
F16	7.5	Automatic track tensioner
F17	10	LE70
F18	7.5	Fuel pump
F19	7.5	Sensors

FUSES		
Position	A	Function
XF3	40	Services
XF4	20	LE70
XF5	70	Start-up
XF26	20	ECU
XF27	20	EGR
RELAY		
Position	Function	
K1	-	
K2	-	
K3	Low engine oil pressure	
K4	Start command	
K5	Radio / manual control	
K6	Horn	
K7	-	
K8	-	
K9	Work headlights	
K10	EGR	
XR2	Power supply	
XR6	Start-up	


6.14.2 - FUSES AND RELAYS ENGINE POWERBOX



FUSES		
Position	A	Function
F1	10	Heater supply
F2	10	+30 Battery fuse
F3	5	Fuel pump supply
F4	-	-
F5	-	-
F6	5	Diagnostic power supply
F7	-	-

RELAY	
Position	Function
R1	Engine power relay
R2	Fuel pump
R3	-
R4	-


6.14.3 - FUSES AND RELAYS ENGINE



FUSES		
Position	A	Function
F200	40	Candle pre-heating

RELAY	
Position	Function
K11	Candle pre-heating

6.15 - EXHAUST GAS POST TREATMENT SYSTEM



1	Differential pressure sensor	2	Exhaust gas inlet
3	Exhaust gas outlet	4	Exhaust gas temperature sensor

6.15.1 - DPF OVERVIEW (DIESEL PARTICULATE FILTER)

The role of DPF is to prevent the discharge into the air of micro-particles harmful to humans and the environment. If the level of micro particles accumulated in it is high, the latter will clog up and consequently reduce the performance of the engine, it is therefore necessary to perform a regeneration when indicated by the Robocut T500.

6.15.2 - DPF MAINTENANCE

- In addition to micro particles, ash also accumulates in the DPF. This is mainly due to metal additives contained in lubricating oil. A small quantity of lubricating oil is burned in the combustion chamber, which is then collected in the DPF together with the combustion gases. This small amount of metallic ash cannot be burned in the DPF. It therefore builds up over time and causes the engine to lose pressure, as well as having other negative effects on it. In this case, by means of a regeneration, clean the DPF.
- Make sure that you use specific fuel and lubricating oil so that the DPF can function correctly. Use a type of diesel fuel with very low sulphur content, according to ASTM D975 or EN590 specifications. If you use a fuel other than the one specified, it might prevent the DPF from being regenerated properly by generating an excessive quantity of particulates. This results in an excessive fuel consumption and the deterioration of the engine (reduced performance) due to the continuous activation of the regeneration process.
- It is also recommended to use a lubricating oil with a low carbon content, otherwise an excessive amount of ash will build-up in the DPF in a short time. This results in an excessive fuel consumption and the deterioration of the engine (reduced performance) due to the continuous activation of the regeneration process. In addition, premature maintenance to the DPF will be necessary.
- The machine owner is responsible for carrying out the necessary maintenance operations, described in this manual and in the coupon manual. The exhaust filter warning indicator on the display or the diagnostic codes indicate when the ash needs to be removed from the particulate filter.
- The failure to respect the methods approved for the removal of the ashes could cause damage to the DPF filter producing the potential annulment of the guarantee on the exhaust filter emissions for diesel engines. Contact McConnell customer care for any servicing information that may be required.

6.15.3 - REGENERATION

The unloading system constantly monitors the DPF clogging condition and engine load conditions during use. This means that if the motor is not used with loads which have power absorptions greater than 60%, the control unit will not easily allow the regeneration operations. The ECU will then determine when regeneration is required by displaying the DPF regeneration request symbol (A) on the display. Once the DPF regeneration request symbol appears on the display, the operator must manually give the regeneration consent.

ATTENTION




Precautions during regeneration:

- Do not carry out the regeneration in enclosed places; the accumulation of gases can cause carbon monoxide poisoning;
- Regeneration involves bringing the exhaust gases to a high temperature so make sure that there are no flammable materials around the machine;
- Regeneration involves bringing the exhaust gases to a high temperature:
 1. Do not touch the end of the exhaust pipe;
 2. Do not stand close to the exhaust pipe;
- Make sure there is enough fuel before starting the exhaust gas filter cleaning process.

How to perform regeneration:

1. The DPF regeneration request symbol (A) appears;
2. Give the DPF regeneration consent by button (B), the symbol (C) will turn green from white.
3. The symbol (D) appears, which will remain present until regeneration is completed;
4. If the DPF regeneration request symbol (A) is ignored for too long, an excessive amount of micro-particles accumulates in the DPF, which can cause errors in the heat engine that depending on their severity can cause the indicator lights (E) and (F) to appear.



A	DPF regeneration request
B	DPF regeneration consent button
C	DPF regeneration go-ahead
D	DPF cleaning in progress
E	Engine error/ warning
F	Serious engine error/ shutdown

6.16 - USE OF THE MACHINE ON UNEVEN GROUND


DANGER




Before moving the machine, ensure full knowledge of the function of the controls and safety standards associated with them. The operator must be in the vicinity of the machine.

Before moving the machine, ensure that nobody is within the operating range of the machine and that the action range is free from obstacles. Exert caution before starting to reverse and always check for the presence of persons, work equipment or obstacles.


- Before starting the shredding operations, check that no foreign bodies such as stones, metal parts and animals are present on the surface;
- Only shred grass and light brushwood that the machine is capable of processing without difficulty;
- In the shredding of slopes always start from below the slope;
- Always turn round in an upwards direction;
- Never go down slopes with an incline of more than 50°;
- Never stop directly in the fall line below the machine.




Never change the direction of the machine while moving on curbs, rocks or surfaces with large differences in height (greater than 20 cm). In these cases, always proceed perpendicular with respect to any obstacles.



When reversing uphill, do not change direction in the transition area between the flat ground and the slope. If it is unavoidable to do so, carry out the manoeuvre gradually.



Avoid moving along the edge of a slope or on uneven ground with one track in a horizontal position and the other inclined or partially raised (with the machine inclined more than approximately 10°). In order not to damage the tracks, always proceed with the sliding blocks resting on the same horizontal plane.



When the machine manoeuvres over an obstacle it creates an empty space between the bearing rollers and the tracks and there is a risk that the track may come out of its seat.

The same may happen if the machine is reversing uphill and you try to make a sharp turn. An empty space is created between the bearing roller, the front idler roller and the track, and there is a risk that it may come out of its seat.

When changing direction and the track cannot move sideways due to an obstacle, the track could become damaged and come out of its seat.

DANGER




SLIPPING OR OVERTURNING

In order to avoid serious risks or the death of the operator it is prohibited to work on slopes that have hard surfaces (e.g. cement). Under these working conditions, always stand behind the machine or sufficiently far away from it (more than 50 metres).

6.17 - CONTROL STATION - OPERATOR WORK AREA

- The minimum lateral distance that the operator must maintain is 10 meters.
- The minimum distance from the front and back of the machine that the operator must maintain is 50 meters. This distance may vary depending on the equipment installed: refer to the user manual of the same.
- The operator should be provided with PPE (shoes, overalls and goggles). If working in very dusty conditions, a protective face mask should be worn.
- The operator must try to position him or herself with respect to the machine in the recommended work cone both to avoid being in the movement area of the machine and in the area where objects might be kicked up. Apart from when working on slopes with an inclination of more than 25°, for which the previous instructions should be followed.



POS.	FORWARD DIRECTION
A	PERMITTED WORK AREA Minimum distance 10 metres.
B	DANGER ZONE Minimum distance 50 meters depending on the tool used

6.18 - ENGINE FAULTS

Given that most of the functioning defects occur because of the improper use of the machine, the following table shows a number of possible malfunctions that could arise and steps to take to avoid them.

WARNING



- Always contact McConnel when carrying out this operation, indicating the machine identification number and the hours of operation.
- If the fault or the reason for it is not indicated in the list of faults shown, contact McConnel in order for repairs to be carried out.

6.18.1 - USING DIAGNOSTIC TROUBLE CODES (DTC)

The diagnostic trouble codes (**DTC**) consist of two parts: the first part (**SPN**) is the number of the system or component that is thought to cause the problem; while the second (**FMI**) is the number that identifies the type of problem that has occurred. To determine exactly what the problem is, both parts of the code are necessary (**SPN** and **FMI**).

For example, the diagnostic code DTC 000110.03 consists of:

	Code	Meaning
SPN:	000110	Engine coolant temperature
FMI:	03	Voltage higher than normal

The combination of the two codes indicates “Excessive voltage of the engine coolant temperature sensor”. Corrective action must therefore be taken, “check sensor and wiring”. If this check does not lead to a solution to the problem, contact McConnel Support Service. Always contact the McConnel Support Service for assistance in processing the diagnostic codes displayed.

6.18.2 - SPN - FMI CODES

SPN	FMI	Description
27	3	EGR valve position #1, Voltage higher than normal
27	4	EGR valve position #1, Voltage lower than normal
29	2	Accelerator pedal position #2, Wrong, intermittent or incorrect
29	3	Accelerator pedal position #2, Voltage higher than normal
29	4	Accelerator pedal position #2, Voltage lower than normal
29	8	Accelerator pedal position #2, Frequency, abnormal pulse width or period
51	3	Engine accelerator position, Voltage higher than normal
51	4	Engine accelerator position, Voltage lower than normal
91	2	Accelerator pedal position #1, Wrong, intermittent or incorrect
91	3	Accelerator pedal position #1, Voltage higher than normal
91	4	Accelerator pedal position #1, Voltage lower than normal
91	8	Accelerator pedal position #1, Frequency, abnormal pulse width or period
97	3	Water-in-fuel indicator, Voltage higher than normal
97	15	Water-in-fuel indicator, High - minimum severity (1)
97	16	Water-in-fuel indicator, High - moderate severity (2)
98	1	Engine oil level, Low - Very severe (3)
98	17	Engine oil level, Low - minimum severity (1)
98	18	Engine oil level, Low - moderate severity (2)
100	1	Engine oil pressure, Low - very severe (3)
100	2	Engine oil pressure, Incorrect, intermittent or incorrect
102	16	Engine intake manifold #1 pressure, High - moderate severity (2)
102	18	Engine intake manifold #1 pressure, Low - moderate severity (2)
105	0	Engine intake manifold #1 temperature, High - Very severe (3)
105	3	Motor intake manifold #1 temperature, Voltage higher than normal
105	4	Motor intake manifold #1 temperature, Voltage lower than normal
105	15	Engine intake manifold #1 temperature, High - minimal severity (1)
105	16	Engine intake manifold #1 temperature, High - moderate severity (2)
107	3	Air filter differential pressure switch, Voltage higher than normal
107	4	Air filter differential pressure switch, Voltage lower than normal
107	15	Air filter differential pressure switch, High - minimum severity (1)
107	16	Air Filter differential pressure switch, High - moderate severity (2)
108	12	Barometric pressure, Fault
110	0	Engine coolant temperature, High - Very severe (3)
110	3	Engine coolant temperature, Voltage higher than normal
110	4	Engine coolant temperature, Voltage lower than normal
110	15	Engine coolant temperature, High - minimum severity (1)
110	16	Engine coolant temperature, High - moderate severity (2)
111	1	Engine coolant level, Low - Very severe (3)
111	17	Engine coolant level, Low - minimum severity (1)
111	18	Engine coolant level, Low - moderate severity (2)
157	3	Engine injector #1 dosing guide pressure, Voltage higher than normal

If the anomaly or its cause does not fall within the indicated faults, contact McConnel for necessary repair.

SPN	FMI	Description
157	4	Engine injector #1 dosing guide pressure, Voltage lower than normal
157	12	Engine #1 injector dosing guide pressure, Fault
157	16	Engine #1 injector dosing guide pressure, High - moderate severity (2)
157	18	Engine #1 injector dosing guide pressure, Low - moderate severity (2)
168	15	Battery potential / Power input #1, High - minimum severity (1)
168	17	Battery potential / Power input #1, Low - minimum severity (1)
168	31	Battery potential / Power input #1, ?
172	3	Engine air inlet temperature, Voltage higher than normal
172	4	Engine air inlet temperature, Voltage lower than normal
174	3	Engine #1 fuel temperature, Voltage higher than normal
174	4	Engine #1 fuel temperature, Voltage lower than normal
174	16	Engine #1 fuel temperature, High - Moderate severity (2)
190	0	Engine speed, High - Very Severe (3)
190	8	Abnormal motor speed, Frequency, pulse width or period
190	10	Abnormal motor speed, Variation speed
190	15	Engine Speed, High - minimum severity (1)
441	0	Auxiliary #1 temperature, High - Very severe (3)
441	3	Auxiliary #1 temperature, Voltage higher than normal
441	4	Auxiliary #1 temperature, Voltage lower than normal
441	15	Auxiliary #1 temperature, High - Minimum severity (1)
441	16	Auxiliary Temperature #1, High - Moderate Severity (2)
515	2	Desired engine operating speed, Incorrect, intermittent or incorrect
558	2	Accelerator pedal #1 Idle switch, Incorrect, intermittent or incorrect
630	2	Calibration memory, Incorrect, intermittent or incorrect
631	2	Personality module, Incorrect, intermittent or incorrect
637	11	Motor timing sensor, Other fault modes
639	9	J1939 network #1, Abnormal update frequency
639	14	J1939 network #1, Special instruction
651	2	Engine injector cylinder #01, Incorrect, intermittent or incorrect
651	5	Engine injector cylinder #01, Current lower than normal
651	6	Engine injector cylinder #01, Current higher than normal
652	2	Engine injector cylinder #02, Incorrect, intermittent or incorrect
652	5	Engine injector cylinder #02, Current lower than normal
652	6	Engine injector cylinder #02, Current higher than normal
653	2	Engine injector cylinder #03, Incorrect, intermittent or incorrect
653	5	Engine injector cylinder #03, Current lower than normal
653	6	Engine injector cylinder #03, Current higher than normal
654	2	Engine injector cylinder #04, Incorrect, intermittent or incorrect
654	5	Engine injector cylinder #04, Current lower than normal
654	6	Engine injector cylinder #04, Current higher than normal
676	5	Engine candle relay, Current lower than normal
676	6	Engine candle relay, Current higher than normal
677	5	Motor ignition relay, Current lower than normal
677	6	Motor ignition relay, Current higher than normal

If the anomaly or its cause does not fall within the indicated faults, contact McConnel for necessary repair.

SPN	FMI	Description
723	8	Abnormal motor speed sensor no. 2, Frequency, pulse width or period
1075	5	Electric engine lift pump for engine fuel supply, Current lower than normal
1075	6	Electric engine lift pump for engine fuel supply, current higher than normal
1076	5	Engine injection pump fuel control valve, Current lower than normal
1076	6	Engine injection pump fuel control valve, Current higher than normal
1231	9	J1939 network #2, Abnormal update frequency
1387	0	Auxiliary #1 pressure, High - Very severe (3)
1387	1	Auxiliary #1 pressure, Low - Very severe (3)
1387	3	Auxiliary #1 pressure, Voltage above normal
1387	4	Auxiliary pressure #1, Voltage below normal
1387	15	Auxiliary Pressure #1, High - minimum severity (1)
1387	16	Auxiliary Pressure #1, High - moderate severity (2)
1387	17	Auxiliary pressure #1, Low - minimum severity (1)
1387	18	Auxiliary pressure #1, Low - moderate severity (2)
2630	3	Engine load air cooler outlet temperature, Voltage higher than normal
2630	4	Engine load air cooler outlet temperature, Voltage lower than normal
2791	6	EGR valve check, Current lower than normal
2791	7	EGR valve check, Does not respond correctly
2882	2	Alternate motor selection, Incorrect, intermittent or incorrect
2970	2	Accelerator pedal #2 Idle switch, Incorrect, intermittent or incorrect
3242	18	Aftertreatment # 1 DPF suction temperature, Low - moderate severity (2)
3251	1	Aftertreatment # 1 DPF Differential pressure, Low - Very severe (3)
3251	3	Aftertreatment # 1 DPF Differential Pressure, Voltage higher than normal
3251	4	Aftertreatment # 1 DPF differential pressure, Voltage lower than normal
3251	13	Aftertreatment # 1 DPF differential pressure, Out of calibration
3251	16	Aftertreatment # 1 DPF differential pressure, High - moderate severity (2)
3251	18	Aftertreatment # 1 DPF differential pressure, Low - moderate severity (2)
3464	6	Engine accelerator actuator #1 Control command, Current higher than normal
3464	7	Engine accelerator actuator #1 Control command, Not responding correctly
3509	3	Sensor #1 supply voltage, Voltage higher than normal
3509	4	Sensor #1 supply voltage, Voltage lower than normal
3510	3	Sensor #2 supply voltage, Voltage higher than normal
3510	4	Sensor #2 supply voltage, Voltage lower than normal
3563	3	Engine intake manifold #1 absolute pressure, Voltage higher than normal
3563	4	Engine intake manifold #1 absolute pressure, Voltage lower than normal
3563	13	Engine intake manifold #1 absolute pressure, Out of calibration
3609	3	DPF #1 intake pressure, Voltage higher than normal
3609	4	DPF #1 intake pressure, Voltage lower than normal
3609	13	DPF #1 suction pressure, Out of calibration
3714	31	Active DPF regeneration inhibited due to temporary system shutdown, ?
3715	31	Active DPF regeneration inhibited due to permanent system blockage, ?
3719	0	DPF #1 soot loading percentage, High - Very severe (3)
3719	16	DPF #1 soot load percentage, High - Moderate severity (2)
4206	9	TSC1 message counter, abnormal update rate

If the anomaly or its cause does not fall within the indicated faults, contact McConnel for necessary repair.

SPN	FMI	Description
4207	9	TSC1 message checksum, abnormal update rate
4765	17	Aftertreatment # 1 diesel oxidation catalyst intake gas temperature, low - minimum severity (1)
5246	0	Aftertreatment SCR operator induction severity, High - Very severe (3)
5246	15	Aftertreatment SCR operator induction severity, High - minimum severity (1)
5246	16	Aftertreatment SCR operator induction severity, High - moderate severity (2)
5298	17	Aftertreatment #1 diesel oxidation catalyst conversion efficiency, Low - minimum severity (1)
5571	0	High pressure Common Rail fuel pressure exhaust valve, High - Very severe (3)
5742	12	Aftertreatment diesel particulate filter temperature sensor module, Fault

If the anomaly or its cause does not fall within the indicated faults, contact McConnel for necessary repair.

6.19 - MACHINE PROBLEMS

Provided that the majority of operating defects occur due to improper use of the machine, the table below indicates some possible malfunctions that could occur and the measures to be taken to eliminate them.

WARNING



- Always contact McConnel when carrying out this operation, indicating the machine identification number and the hours of operation.
- If the fault or the reason for it is not indicated in the list of faults shown, contact McConnel in order for repairs to be carried out.

6.19.1 - TROUBLESHOOTING CONTROL UNIT LE70

Error	Cause	Size
10	Longitudinal machine angle excessive with respect to the ground	Decrease the inclination of the machine
11	Transverse machine angle excessive with respect to the ground	Decrease the inclination of the machine
12	Water temperature fairly high	Allow the engine to cool down
13	Water temperature high, stop the stump grinder for safety	Allow the engine to cool down
14	Water temperature very high, switch off the engine for safety	Allow the engine to cool down
40	LE70 1 safety relay contact error	Check the control unit power supplies, save the parameters. If the error persists, replace the control unit
41	LE70 2 safety relay contact error	Check the control unit power supplies, save the parameters. If the error persists, replace the control unit
42	LE70 3 safety relay contact error	Check the control unit power supplies, save the parameters. If the error persists, replace the control unit
43	LE70 4 safety relay contact error	Check the control unit power supplies, save the parameters. If the error persists, replace the control unit
44	Control unit RTC error	Save the parameters. If the error persists, replace the control unit
50	LE70 CRC Error	Reprogram the control unit, save the parameters. If the error persists, replace the control unit
51	LE70 CRC Error	Reprogram the control unit, save the parameters. If the error persists, replace the control unit
52	LE70 CRC Error	Reprogram the control unit, save the parameters. If the error persists, replace the control unit
53	LE70 CRC Error	Reprogram the control unit, save the parameters. If the error persists, replace the control unit
55	No power to the LE70	Make sure there is power on pins A33 and B33
60	Receiver error message CAN Autec Radio	Check the receiver, check the CAN line, check the LE70. If the error persists, replace the IO Bridge
61	Receiver error message CAN Autec Radio	Check the receiver, check the CAN line, check the LE70. If the error persists, replace the IO Bridge

If the fault or the reason for it is not indicated in the list of faults shown, contact McConnel in order for repairs to be carried out.

Error	Cause	Size
62	Receiver error message CAN Autec Radio	Check the receiver, check the CAN line, check the LE70. If the error persists, replace the IO Bridge
63	Receiver error message CAN Scanreco Radio	Check the receiver, check the CAN line, check the LE70. If the error persists, replace the IO Bridge
64	Receiver error message CAN Scanreco Radio	Check the receiver, check the CAN line, check the LE70. If the error persists, replace the IO Bridge
65	System error Scanreco radio	If the error persists, replace the radio transmitter / receiver unit
70	Radio control lever value incorrect	Check the remote control, check the control unit parameters. If the error persists, replace the remote control
71	Radio control lever value incorrect	Check the remote control, check the control unit parameters. If the error persists, replace the remote control
72	Radio control lever value incorrect	Check the remote control, check the control unit parameters. If the error persists, replace the remote control
73	Radio control lever value incorrect	Check the remote control, check the control unit parameters. If the error persists, replace the remote control
74	Radio control lever value incorrect	Check the remote control, check the control unit parameters. If the error persists, replace the remote control
75	Radio control lever value incorrect	Check the remote control, check the control unit parameters. If the error persists, replace the remote control
76	Radio control lever value incorrect	Check the remote control, check the control unit parameters. If the error persists, replace the remote control
77	Radio control lever value incorrect	Check the remote control, check the control unit parameters. If the error persists, replace the remote control
80	Receiver error message CAN from machine display	Check the display, check the CAN line, check the LE70. If the error persists, replace the display
81	Machine display system error	If the error persists, replace the display
90	Machine inclinometer system error	If the error persists, replace the inclinometer
91	Receiver error message CAN from the inclinometer;	Check the inclinometer, check the CAN line, check the LE70, if the error persists, replace the inclinometer
200	Engine protection alarm;	See SPN and FMI codes to understand the reason for the alarm
201	Engine warning alarm;	See SPN and FMI codes to understand the reason for the alarm
202	Stop engine alarm;	See SPN and FMI codes to understand the reason for the alarm
203	Engine fault alarm	See SPN and FMI codes to understand the reason for the alarm
204	Engine alarm	Battery voltage: the voltage measured by the ECU is outside the target range
205	Engine alarm	Battery voltage: the voltage measured by the ECU is outside the target range; the ECU activates a system response

If the fault or the reason for it is not indicated in the list of faults shown, contact McConnel in order for repairs to be carried out.

Error	Cause	Size
206	Engine alarm	Coolant level: the level of coolant calculated by the ECU is less than the minimum permitted amount
207	Engine alarm	Air heater relay indicator: the energy consumption measured by the ECU does not fall within the permissible range or the maximum permissible temperature of the ECU component that powers the lamp has been exceeded
208	Engine alarm	Coolant temperature sensor: the sensor voltage measured by the control unit does not fall within the permissible range; the temperature of the coolant calculated by the control unit is questionable when compared to the oil temperature, or the value received via the CAN is incorrect
209	Engine alarm	Coolant temperature: the temperature of the coolant calculated by the control unit is higher than the permissible range; the ECU activates a system response
210	Engine alarm	Oil level indicator: the energy consumption measured by the ECU does not fall within the permissible range or the maximum permissible temperature of the ECU component that powers the lamp has been exceeded
211	Motor CAN message reception error;	Check the engine, check the CAN line, check the LE70. If the error persists, check the engine control unit.
500	Problems with output pin A24 of control unit LE70	Check the cable; Controller output error;
501	Problems with output pin A13 of control unit LE70	Check the cable; Controller output error;
502	Problems with output pin A01 of control unit LE70	Check the cable; Controller output error;
503	Problems with output pin A02 of control unit LE70	Check the cable; Controller output error;
504	Problems with output pin A03 of control unit LE70	Check the cable; Controller output error;
505	Problems with output pin A04 of control unit LE70	Check the cable; Controller output error;
506	Problems with output pin A05 of control unit LE70	Check the cable; Controller output error;
507	Problems with output pin A06 of control unit LE70	Check the cable; Controller output error;
508	Problems with output pin A07 of control unit LE70	Check the cable; Controller output error;
509	Problems with output pin A08 of control unit LE70	Check the cable; Controller output error;
510	Problems with output pin A09 of control unit LE70	Check the cable; Controller output error;
511	Problems with output pin A10 of control unit LE70	Check the cable; Controller output error;
512	Problems with output pin A11 of control unit LE70	Check the cable; Controller output error;
513	Problems with output pin A12 of control unit LE70	Check the cable; Controller output error;
514	Problems with output pin A23 of control unit LE70	Check the cable; Controller output error;
515	Problems with output pin A35 of control unit LE70	Check the cable; Controller output error;
516	Problems with output pin B24 of control unit LE70	Check the cable; Controller output error;
517	Problems with output pin B13 of control unit LE70	Check the cable; Controller output error;
518	Problems with output pin B01 of control unit LE70	Check the cable; Controller output error;
519	Problems with output pin B02 of control unit LE70	Check the cable; Controller output error;
520	Problems with output pin B03 of control unit LE70	Check the cable; Controller output error;
521	Problems with output pin B04 of control unit LE70	Check the cable; Controller output error;
522	Problems with output pin B05 of control unit LE70	Check the cable; Controller output error;

If the fault or the reason for it is not indicated in the list of faults shown, contact McConnel in order for repairs to be carried out.

Error	Cause	Size
523	Problems with output pin B06 of control unit LE70	Check the cable; Controller output error;
524	Problems with output pin B07 of control unit LE70	Check the cable; Controller output error;
525	Problems with output pin B08 of control unit LE70	Check the cable; Controller output error;
526	Problems with output pin B09 of control unit LE70	Check the cable; Controller output error;
527	Problems with output pin B10 of control unit LE70	Check the cable; Controller output error;
528	Problems with output pin B11 of control unit LE70	Check the cable; Controller output error;
529	Problems with output pin B12 of control unit LE70	Check the cable; Controller output error;
530	Problems with output pin B23 of control unit LE70	Check the cable; Controller output error;
531	Problems with output pin B35 of control unit LE70	Check the cable; Controller output error;

If the fault or the reason for it is not indicated in the list of faults shown, contact McConnel in order for repairs to be carried out.

6.19.2 - ELECTRICAL CIRCUIT

Provided that the majority of operating defects occur due to improper use of the machine, the table below indicates some possible malfunctions that could occur and the measures to be taken to eliminate them.

WARNING



- Always contact McConnel when carrying out this operation, indicating the machine identification number and the hours of operation.
- If the fault or the reason for it is not indicated in the list of faults shown, contact McConnel in order for repairs to be carried out.

Malfunctions	Causes	Measurements
The lights are not properly lit even when the engine is running at a high speed	Faulty cables	Check and repair the defective terminals and cables
The lights are not steadily lit while the engine is running	Defective fan belt tensioning	Adjust belt tensioning
Alternator charging lamp does not turn off when the engine is running and is accelerated	Alternator faulty	Replace
	Faulty cables	Replace
The starter does not run when the key is turned to the ignition	Faulty cables	Check and repair
	Insufficient accumulator charge	Charge the accumulator
	Faulty main fuse	Replace
The starter pinion is engaged and then released	Insufficient accumulator charge	Charge the accumulator
The starter makes the engine run slowly	Insufficient accumulator charge	Charge the accumulator
	Faulty starter	Replace
The starter deactivates before the engine starts	Faulty cables	Check and repair
	Insufficient accumulator charge	Charge the accumulator
The alternator charge indicator light does not turn on when the engine is stopped (ignition key on "I")	Faulty light	Replace
	Faulty cables	Check and repair

If the anomaly or its cause does not fall within the indicated faults, contact McConnel for necessary repair.

6.19.3 - HYDRAULIC SYSTEM

Provided that the majority of operating defects occur due to improper use of the machine, the table below indicates some possible malfunctions that could occur and the measures to be taken to eliminate them.

WARNING



- Always contact McConnel when carrying out this operation, indicating the machine identification number and the hours of operation.
- If the fault or the reason for it is not indicated in the list of faults shown, contact McConnel in order for repairs to be carried out.

Malfunctions	Causes	Measurements
The pump makes a strange noise.	Faulty pump	Repair or replace.
	Lack of oil in the tank	Fill to level
The equipment moves at low speed.	Faulty pump	Repair or replace.
	Maximum pressure valve out of calibration or not closed due to impurities	Calibrate or replace.
	Dirty discharge filter	Replace the cartridge

If the anomaly or its cause does not fall within the indicated faults, contact McConnel for necessary repair.

6.19.4 - TROUBLESHOOTING THE RADIO CONTROL

Given that most of the functioning defects occur because of the improper use of the machine, the following table shows a number of possible malfunctions that could arise and steps to take to avoid them.

WARNING



- **Always contact McConnel when you have to carry out this operation, indicating the machine identification number and its hours of operation.**
- **If the fault or the reason for it is not indicated in the list of faults provided, contact McConnel in order for repairs to be carried out.**

6.19.4A - TRANSMITTER FAULTS

Malfunctions	Causes	Measures
The green LED flashes rapidly. The red LED flashes for 3.5 minutes	The battery is not sufficiently charged or the transmitter has been on for eight hours	The battery has to be replaced with one that is charged or switch off the transmitter and restart the radio control
The green LED flashes once or twice and then pauses. The red LED flashes for 3.5 minutes		
The green LED flashes three times and then pauses. The red LED flashes for 3.5 minutes	The transmitter unit has been on for eight hours	Switch off the transmitter unit and restart the radio control
The green LED is off. The red LED gives one long flash.	The transmitter is not working properly	Contact McConnel Customer Care
When the radio control is started, the green LED is off and the red LED gives one long flash.	The emergency stop button is pressed	Disengage the emergency button
When the radio control is started, the green LED is off and the red LED gives two long flashes.	The transmitter is not working properly	Contact McConnel Customer Care
When the radio control is started, the green LED is off and the red LED gives three long flashes.	The battery is very low	Replace the battery with one that is charged
When the radio control is started, the green LED is off and the red LED gives four long flashes.	The SAFETY controller is active	Move the actuators into the rest position
When the radio control is started, the green LED is on and the red LED gives several short flashes.	At least one of the actuators (level switches)	Move the actuators into the rest position
When the radio control is started, the green LED is on and the red LED gives two long flashes and several short flashes.	At least one of the actuators (potentiometers)	Move the actuators into the rest position
When the radio control is started, the green LED is on and the red LED gives three long flashes and several short flashes.	At least one of the actuators (joystick)	Move the actuators into the rest position
When the radio control is started, the green LED is on and the red LED gives four long flashes and several short flashes.	At least one of the actuators (joystick)	Move the actuators into the rest position

If the fault or the reason for it is not indicated in the list of faults provided, contact McConnel in order for repairs to be carried out.

- Each time the red LED comes on, the audible warning device is activated.
- After the red LED has flashed for 3.5 minutes, the transmitter unit switches off.
- To view the warning messages when starting the radio control, press and hold the START button until the transmitter switches off.

6.19.4B - IDENTIFYING THE ACTIVE COMMAND

- If the green LED is on, it indicates that at least one of the commands of the actuators is active when the radio control has been started.
- The active command is identified by a series of long flashes followed by short flashes of the red LED as described in the following table.
- Each time the red LED comes on, the audible warning device is activated.

Green LED	Number of red LED flashes		Actuator active
	Long	Short	
On	1	2	D2
On	1	3	D3
On	1	4	D4
On	1	5	D5
On	1	6	D6
On	1	7	D7
On	1	8	D8
On	1	9	D9
On	1	10	D10
On	1	11	D11
On	1	12	D12
On	1	13	D13
On	1	14	D14
On	1	15	D15
On	1	16	D16
On	1	17	D17
On	1	18	D18
On	1	19	D19
On	1	20	D20
On	2	1	A1
On	2	2	A2
On	2	3	A3
On	2	4	A4
On	2	5	A5
On	2	6	A6
On	2	7	A7
On	2	8	A8
On	3	1	H1
On	3	2	H2
On	3	3	H3
On	3	4	H4
On	3	5	H5
On	3	6	H6
On	3	7	H7
On	3	8	H8
On	4	1	L1
On	4	2	L2

If the fault or the reason for it is not indicated in the list of faults provided, contact McConnel in order for repairs to be carried out.

Green LED	Number of red LED flashes		Actuator active
	Long	Short	
On	4	3	L3
On	4	4	L4
On	4	5	L5
On	4	6	L6
On	4	7	L7
On	4	8	L8

If the fault or the reason for it is not indicated in the list of faults provided, contact McConnel in order for repairs to be carried out.

Examples

- If the red LED gives one long flash and three short flashes, it means that the transmitter unit has detected that command D3 is active.
- If the red LED gives two long flashes and six short flashes, it means that the transmitter unit has detected that command A6 is active.
- If the red LED gives three long flashes and two short flashes, it means that the transmitter unit has detected that command H2 is active.
- If the red LED gives four long flashes and one short flash, it means that the transmitter unit has detected that command L1 is active.

6.19.4C - RECEIVER FAULTS

The table below indicates malfunctions that can be identified by the switching on of the LEDs on the receiver unit.

If the problem persists after having tried the suggested solution, contact the McConnel Customer Care.

Malfunctions	Causes	Measures
The POWER LED is off	The receiver is off	Check the power supply fuse. Connect the plug correctly and power up the receiver unit
	There is an error on output STP_1	Check the fuse of output STP_1. Correctly couple the connecting plug. Check the wiring of output STP_1
	There is an error on output STP_2	Check the fuse of output STP_2. Correctly couple the connecting plug. Check the wiring of output STP_2
	There is an error on output SAF_1	Check the fuse of output SAF_1. Correctly couple the connecting plug. Check the wiring of output SAF_1
	There is an error on output SAF_2	Check the fuse of output SAF_2. Correctly couple the connecting plug. Check the wiring of output SAF_2
The STATUS LED flashes slowly	There is an overvoltage in the power supply	Check that the power supply of the receiver is within the voltage limits specified in the technical data
The STATUS LED is flashing rapidly and discontinuously	The receiver loses some of the data sent by the transmitter	Move the transmitter closer to the receiver. If this warning persists contact McConnel Customer Care
The RUN LED is flashing	The receiver is not sending commands to the CAN network	Contact McConnel customer care
The ERR LED is flashing	There is a CAN communication error	
	The receiver has activated the automatic stop function (ATS) as it carries out a self-test every eight hours of continuous operation	Start the radio control
The SETUP LED flashes twice	There is an error in the memory card	Contact McConnel customer care


If the fault or the reason for it is not indicated in the list of faults provided, contact McConnel in order for repairs to be carried out.

7 - TRANSPORTATION AND HANDLING

7.1 - LOADING AND UNLOADING OPERATIONS FOR ROAD TRAVEL

Use suitable vehicles with a carrying capacity of greater than 1200 kg to transport the machine. Use two loading ramps, both of which are suitable for supporting a load of not less than 600 kg and which are hooked to the bed of the vehicle. The ramps must be positioned at the correct distance for the tracks and must make an angle with respect to the ground of no more than 50°.

Once the machine has been loaded onto the vehicle, it is recommended to secure it to the bed of the vehicle using wire ropes or slings attached to the lifting rings indicated below.



ATTENTION



THEY COULD DAMAGE THE SURFACE!

If studded tracks are mounted on the machine, cover the tracks with suitable rubber pads if it has to travel across concrete or tarmacked surfaces.



7.2 - LIFTING THE MACHINE

ATTENTION




Do not attach wire ropes or slings to the roll bar in order to lift the machine. This element is not designed for lifting the machine.


If the machine has to be lifted in order to load it, make sure that you use suitable chains or wire ropes for lifting and loading it.

7.2.1 - LIFTING POINTS

Connect the ropes or the chains to the lifting rings provided (A). The machine should always be lifted without the equipment attached.



Note that when using ropes, slings or chains to lift the machine, it is necessary to comply with the diagram below, indicating the minimum pulling angles.



Angle at the top	Load increase factor
0°	1
10°	1004
20°	1015
30°	1035
40°	1064
50°	1103
60°	1155
70°	1221
90°	1414
100°	1556
110°	1743
120°	2000
130°	2336
140°	2924
150°	3864
160°	5759
170°	11474

POS.	DESCRIPTION
α	Rope opening angle
A	Distance between the coupling points
B	Rope angle with horizon
C	Load increase factor
D	A/L
L	Rope length

7.3 - IF THE MACHINE BREAKS DOWN

ATTENTION



- Lift the machine in the appropriate preset points, using ropes or chains suitable for lifting.
- Do not attach wire ropes or slings to the roll bar in order to lift the machine. This element is not designed for lifting the machine.
- If equipment is attached to the machine, it must be disconnected and moved at a later stage (refer to the equipment manual for lifting instructions).

If the heat engine or the hydraulic system break down, do not tow the machine. Only lift.

7.4 - USING THE MANUAL CONTROL (OPTIONAL)

If there is a need to move the machine even without the remote control (e.g. discharged remote control batteries), the operation can be carried out by connecting the manual control provided as an option.

To do this, follow the instructions below:





1. Remove the cap with the bayonet fitting (B) from the socket (A);
2. Insert the male connector (C) into the socket (A) and tighten the retaining ring nut (D).

The engine can now be started using the ignition key.

ATTENTION



Only use the manual control in the event of emergencies.



POS.	DESCRIPTION
1	Left track forward
2	Left track in reverse
3	Lift lifting device
4	Lower lifting device
5	Right track forward
6	Right track in reverse

7.5 - STARTING WITH AN AUXILIARY BATTERY

ATTENTION





Do not use ignition systems such as electric chargers or boosters, they could cause possible failures of the electronic control units.

DANGER




- Never check the battery charge by connecting the two poles with a metal object. Use a voltmeter.
- The battery earth connector (-) must always be the first to be disconnected and the last to be re-connected.
- The sulphuric acid in the battery electrolyte is poisonous. It can burn skin, pass through tissue and cause blindness if it enters the eyes.
- It should be noted that its compounds cause cancer and other harm to the reproductive organs. These substances are present in the battery poles, terminals and relative accessories. Wash your hands after touching them.



If the engine has to be started using an auxiliary battery, proceed as follows:

1. Untighten the two screws (A), tilt towards the extruder and then remove the lower right side bonnet (B);
2. Open the cover of the branch node (C);
3. Connect one terminal of the red cable to the screw of the node (C) and the other to the positive terminal (+) of the auxiliary battery.
4. Ground one end of the black cable, attaching it either to the heat engine or to one of the four masses of the frame and the other end, to the negative pole (-) of the auxiliary battery.
5. The engine can now be started using the ignition key.
6. Bring the heat engine to 1000 rpm and wait a few minutes before disconnecting from the auxiliary battery.



8 - STORAGE

Before storage it is advisable to operate as follows:

- Free the machine components (e.g. filters, radiators, cylinders and/or all moving parts) from any shredding or other residues;
- Free the components of the connected equipment (e.g. rotor, tools, cylinders and/or all parts in movement) from any shredding or other residues;
- Clean and wash the machine and the equipment connected to it thoroughly;
- Properly lubricate all mechanical parts subject to friction, as described herein manual;
- Check the entire structure for any breakages/cracks, if compromised do not use the equipment anymore, contact McConnel Support Service
- Check the integrity of the protections and safety devices, if necessary replace them;
- Detect any abrasions that have compromised the painting, if necessary restore it;
- Check the presence and integrity of all safety pictograms, if necessary replace them.

If the equipment is put to rest for long periods, it is appropriate to operate as follows:

- Place it indoors, in a room sheltered from atmospheric agents, humidity and dust;
- Make sure that the storage temperature is between 0 °C and 40 °C;
- Place it on a solid and flat surface, checking the correct positioning and then the stability once positioned on the ground.
- Connect a charge maintainer to the battery. If you do not have a charge maintainer, disconnect the battery (s), disconnecting the negative pole.

8.1 - FIRST USE OR COMMISSIONING AFTER A LONG PERIOD OF INACTIVITY

Before using the equipment for the first time, or after a long period of inactivity, proceed as follows:

- Check that the equipment is not damaged;
- Check the mechanical parts, which must be in a good condition and not rusty;
- Check the state of wear of the tools (if any);
- Carefully grease all moving parts;
- Check that there are no oil leaks coming from fittings or pipes;
- Check that all the protections are correctly positioned;
- Check the status of the battery (s).

8.2 - DISMANTLING, DECOMMISSIONING

- If you no longer wish to use the machine, or parts of it, it is necessary to dismantle and decommission the machine.
- Before scrapping, the plastic/rubber parts and electrical and electronic materials must be separated.
- Collect any waste oil and dispose of it at the appropriate collection centres.
- Carry out these operations according to the regulations in force.

ATTENTION

If the machine or part of it has been taken out of service, the parts likely to cause any danger must be made harmless.

ATTENTION

- It should be remembered that when replacing oils, batteries, rubber tubes, tyres and any parts of the machine subject to separate disposal, reference must always be made to the applicable regulations.
 - For the collection of waste oil, use a reputable hazardous waste disposal company.
-

9 - MAINTENANCE

9.1 - INTRODUCTION

To obtain the best performance from the machine and ensure maximum durability for all parts, it is necessary that the rules of use and maintenance are scrupulously followed by the employees of the machine.

It is therefore advisable that the Customer, in their own interest, carefully read these notes and consult the manual whenever they need a suggestion to delete a possible problems. As the machine operates normally in contact with water, sand, earth, etc., regular lubrication is necessary, which assumes vital importance not only to ensure lengthy use of the machine, but also to keep down its running costs.

For more information contact McConnel Support Service:

Telephone	+44 (0)1584 873131
Email	sales@mcconnel.com

9.2 - GENERAL INSTRUCTIONS

- - Before carrying out any maintenance or inspecting and / or checking the machine, turn off the diesel engine and remove the ignition key.
- While disassembling and reassembling machine parts, always use suitable extractors, wrenches and tools to avoid damaging the specified components.
- To unlock parts that are stuck, use wooden hammers.
- Separate the parts of the various units and partially screw in the nuts on their corresponding pins or stud bolts. Clean the parts using brushes or rags, then wash using petroleum or warm water and remove all residues using compressed air.
- After sandblasting or finishing operations with abrasive elements, thoroughly clean the parts making sure that all abrasive powder residues have been removed completely.
- When reassembling the parts, make sure that they are clean. Then, lubricate them appropriately.
- Pay great attention to the safety rings and lock pins. Replace them immediately if you notice breaks.
- The maintenance operations of the machine and/or equipment must be carried out by authorised personnel.

9.3 - EXTRAORDINARY INTERVENTIONS

These are repairs or replacements of one or more components of the machine, which usually become necessary after a few years of efficient operation and which do not alter the characteristics of the machine. In the case of considerable changes, the manufacturer shall not be held responsible for possible hazards which might arise. These interventions must be performed by authorised personnel.

9.4 - FLUIDS AND GREASES

9.4.1 - LUBRICANTS TABLE

COMPONENT	RECOMMENDED LUBRICANT	INTERNATIONAL SPECIFICATIONS
HEAT ENGINE	Q8 FORMULA TRUCK 8600 10W-40	API CJ-4
	10W-40 15W-40	API CK-4 ACEA E9 ECF-3
HYDRAULIC SYSTEM Mineral Oil	• ISO 46 • Q8 HELLER 46	DIN 51 524, 2-HLP DIN 51 524, 3-HLP API CD, CE, CF
HYDRAULIC SYSTEM Biodegradable Oil	Q8 HOLBEIN HP SE Bio 46	ISO 11158 Category HV Din 51524, Part 3 Category HVLP ISO 15380 / CEC-L33-A-93 - Water Hazard Class (VwVwS) WGK 1 - Category HEES
	PANOLIN BIO HLP SYNTH E	FZG Test A/8.3/90 stage 12 ISO 15380 HEES
PINS AND BUSHINGS	• PAKELO MOLY GREASE • NLGI 2	Black grease with lithium soaps added with Molybdenum Bisulfide.
	• PAKELO CONTACT GREASE • NLGI2	Purple grease with lithium soaps. Recommended in case of automatic greasing.
BEARINGS	• PAKELO GREENPLEX EP • NLGI 1.2	Green grease with complex aluminium soaps.
ROLLERS, IDLER WHEELS, TRACK TENSIONER and PINS	• PAKELO WHITE EP GREASE • NLGI 2	White grease with lithium soaps.

ATTENTION



- When using hydraulic biodegradable oils, avoid mixing them with more than 5% of other oils.
- The use of non-recommended lubricants and/or greases will result in invalidity of the warranty.

9.4.2 - COOLANT

DANGER



- When handling the fuel or coolant, do not smoke or work near heat sources or sparks.
- Store the coolant away from areas at risk of fire. Do not incinerate or burn containers; make sure the machine is free from dirt, grease or inflammable residues.

In the Robocut T500, Q8 ANTIFREEZE LONG LIFE is used as the coolant.

- Q8 ANTIFREEZE LONG LIFE diluted in deionized/demineralized water becomes a permanent coolant that can be used year-round.
- To ensure perfect mixing, it is essential to mechanically mix the antifreeze liquid with dilution water.
- The antifreeze protection depends on the proportion of Q8 ANTIIFREEEE LONG LIFE diluted in water.

Volume to dilute out of total	%	33	50
Temperature reached for the appearance of the first crystals	°C	-18	-38

- To ensure adequate corrosion protection, the coolant solution must contain at least 33% Q8 Antifreeze Long Life.
- It is recommended to use at least 50% by volume of Q8 Antifreeze Long Life in the final mixture.
- Dilution with deionized water is preferred.

Q8 Antifreeze Long Life meets the main international specifications on antifreeze: ASTM D 3306; ASTM D 4656; ASTM D 4985, ASTM D 6210; JIS K 2234; SAE J 1034.

9.4.3 - FUEL

DANGER

- Do not use diesel filling systems that use auxiliary electric pumps without the written consent of McConnel.
- It is forbidden to tamper with or modify the fuel supply system and/or electrical system.

DANGER

- When handling fuel or coolant, do not smoke or work near a source of heat or sparks.
- Store flammable fluids away from fire hazards. Do not incinerate or burn containers; make sure the machine is free from dirt, grease or inflammable residues.

We recommend using standard-compliant fuels:

Fuel specifications	Position
EN590	European Union
ASTM D975 N.1D S15"	USA
ASTM D975 N.2D S15"	USA
JIS K2204	Japan
BS 2869: CLASS 2010 EQUIVALENT A2 O EU	United Kingdom

Other fuels with different specifications can damage the engine or reduce its power. For further details and/or explanations, consult the annexed engine manual.

1. When refuelling, check that there is no condensate on the fuel tank cover. Do not remove the condensate water on the bottom.
2. Having run out of fuel or after the fuel filter has been changed, bleed the air from the pipes.

9.5 - ENGINE MAINTENANCE


9.5.1 - CHECK ENGINE OIL LEVEL

ATTENTION





- The motor oil level must be checked *daily*.
- The choice of engine oil must be made with the utmost care; refer to the table in paragraph "9.4.1 Lubricant table".

The level of the engine oil can be checked with the graduated rod (A). The level must be between the MIN. and MAX. signs. The engine oil level must be checked with the engine cold and with the machine parked on flat surface.



If the engine oil level is near the MIN sign, restore it by unscrewing the cap (B) and adding oil until the level is between MIN. and MAX. To check this situation while topping up, wait a few moments before carrying out the check.



DANGER



- The heat engine just switched off can be very hot so do not check the engine oil until the engine itself is cold.
- When checking the oil level or filling up, use protective clothing.

WARNING



Oil level above MAX level could cause shaft immersion engine in the oil; the air bubbles that form reduce the characteristics of oil lubricants and could cause power loss or failure.

9.5.2 - FILTER AND ENGINE OIL CHANGE

ATTENTION

- Replace the filter and heat engine oil *every 500 hours or 1 year*.
- Quantity of oil to be used: *about 7.5 litres*.
- The choice of engine oil must be made with the utmost care; refer to the table in paragraph "9.4.1 Lubricant table".

WARNING

- The used oil and filter are classified as hazardous waste and must be disposed of correctly.
- Do not dispose of with household waste.
- Contact your local authorities, support centre or dealer for disposal/recycling centres.



DANGER


Do not perform these operations:

- **Danger of burns:** Wait for the engine to become warm.
- Oil spilled during the replacement may cause slipping; wear protective garments and non-slip footwear and remove any traces of oil.


Perform the operations listed below to replace the filter and thermal motor oil:

1. Run the engine for about five minutes to heat the oil to idle speed.
2. Place the machine flat, turn off the engine and remove the ignition key.
3. Remove the bottom protection (A) by first untightening the four screws (B) with a 13 mm wrench.
4. Place a container under the engine to collect the used.
5. Untighten the oil sump drain cap (C) with a 19 mm wrench.
6. Clean the inspection and top-up area to reduce the possibility of contaminating the engine oil with impurities.





7. Unscrew the oil filler cap (D);
8. Retighten the oil sump drain cap (C) once all the oil has drained out;
9. Remove the left side protection (E): untighten the two screws that fix it; tilt it and then lift it;
10. Untighten the filter (F) counterclockwise and remove it;



11. Apply a film of clean oil to the new filter in the external and internal seals, and the filter thread;
12. Dry the filter sealing head thoroughly with a clean cloth and reassemble the filter by tightening it by hand;
13. Fill using suitable engine oil (see **"9.4.1 Lubricant table"**) and close the load cap (D).
14. Start the engine and leave it running for about five minutes at idle speed, then turn off the engine and after about three minutes check the engine oil level using the appropriate rod (G). If necessary, top up.
15. Refit the bonnets (A) and (E).

9.5.3 - COOLANT LEVEL CHECK

ATTENTION


- Check the coolant level *daily* or *before each use*.
- The choice of coolant must be made with the utmost care; refer to the table in paragraph "9.4.2 Coolant".
- If the level is too low, it can cause irreparable damage to the engine.
- Radiator under pressure, hot engine do not open the cap.

DANGER

- Danger of burns due to very hot coolant!
- The cooling system is under pressure! If pressurised coolant spurts out, it may cause serious injuries.
- Before removing the cap, loosen it slowly until the first stop to relieve the pressure inside.
- Remove the fuel filler cap only when it has cooled down enough to be touched with the bare hand.
- When handling fuel or coolant, do not smoke or work near heat sources or sparks.

Proceed as follows to check the coolant level:

1. Detach the two rubber stay rods (B) securing the bonnet (A).
2. Pull the locking pin (C), raise the bonnet, then block it by releasing the pin.
3. Slowly unscrew the radiator cap (D) in order to release the pressure inside and visually check the coolant level.
4. The level of coolant must be above the radiator elements by two or three centimetres.
5. If the level is low, restore it by adding coolant to the radiator. Close the cap (D).
6. Pull the locking pin (C). Lower the bonnet (A) and block it with the two stay rods.



9.5.4 - COOLANT REPLACEMENT

ATTENTION



- The coolant must be replaced every *3000 working hours* or after *2 years*.
- Before removing the cap, loosen it slowly until the first stop to relieve the pressure inside.
- The choice of coolant must be made with the utmost care; refer to the table in paragraph "9.4.2 Coolant".
- Do not fill the cooling system at a speed greater than 5 litres per minute to avoid the formation of air pockets: air in the cooling system may cause damage to the engine.

DANGER




- Danger of burns due to very hot coolant!
- The cooling system is under pressure! If pressurised coolant spurts out, it may cause serious injuries.
- Before removing the cap, loosen it slowly until the first stop to relieve the pressure inside.
- Remove the fuel filler cap only when it has cooled down enough to be touched with the bare hand.
- When handling fuel or coolant, do not smoke or work near heat sources or sparks.

DANGER




- Dispose of spilled coolant in accordance with the relative standards and do not allow it to penetrate the ground.
- The improper disposal of waste can threaten the environment and the ecological system. For disposal or correct recycling of waste, contact the relevant agencies.
- The protective agents of the cooling system must be ordered from McConnel partners.
- Never use the engine without coolant, not even for a short time!




To replace the coolant, proceed as described:

1. Position the machine on a flat surface and switch off the engine;
2. Allow the coolant and engine to cool down;
3. Detach the two rubber stay rods (B) securing the bonnet (A).
4. Pull the locking pin (C), raise the bonnet and block it by releasing the pin.
5. Slowly unscrew the radiator cap (D) to the first stop to release the pressure inside the circuit. When done, remove it.



6. Remove the guard (E) by unscrewing the four screws which hold it in place, using a 10-mm spanner.
7. Place a container under the engine and radiator to collect the used coolant.
8. Unscrew the drain cap (F) from the radiator, with a socket wrench (G) with a 22-mm socket.
9. Remove the drain plug (H) from the engine.



10. Drain the coolant from the radiator.
11. After having drained the coolant, wash the radiator and monobloc with water and a suitable detergent in order to remove any rust, scale and contaminants.
12. Screw the drain plug (H) back on the engine and tighten it; screw the drain plug (F) back on the radiator and tighten it.
13. Replace the guard (E) by tightening the four fixing screws.

14. Fill the engine and radiator with coolant, making sure that the level of liquid is between two and three centimetres above the radiator elements.
15. Tighten the radiator filler cap (**D**).
16. Start the engine and let it run at idle for a minimum of 30 minutes until it reaches normal operating temperature; the coolant temperature should be at least 82°C.
17. Reduce engine speed to idle, then turn off the engine.
18. Allow the coolant and engine to cool down.
19. Check the coolant level again and top it up, if necessary.
20. Close the bonnet (**A**) by locking it using the two tie rods (**B**).

9.5.5 - FUEL LEVEL CHECK

ATTENTION

- Check the fuel level daily or before each use.
- The fuel must be chosen very carefully; refer to the table in the "9.4.3. Fuel" section.

DANGER

- When more fuel is added, avoid spilling it as this may cause a risk of fire.
- If some fuel is spilled accidentally, clean the area very carefully.
- Fuel is a highly flammable liquid so do not use open flames and do not smoke while refuelling. Also hold the nozzle or the canister close to the filler neck to prevent sparks.
- When adding fuel wear protective clothing.

The fuel level is checked visually with the machine on the flat, on the remote control or machine display.


If the level falls to reserve a warning light comes on and a beeper sounds.

To top up the fuel:

1. Turn off the engine.
2. Open the tank cap (A) with the key supplied with the machine and fill it. Do not fill the tank right to the top. Leave a gap for expansion.
3. Lock the cap with the key.

WARNING

To facilitate the filling of the tank, it is recommended to use funnels or other aids free of residues of other liquids and/or solids other than diesel fuel.



9.5.6 - DRAINAGE AND VENTING OF THE FUEL DECANter

ATTENTION



- Check the fuel decanter *every 8 hours or daily*.
- When contaminants appear, remove them immediately, **DO NOT** wait for scheduled maintenance to be carried out.
- The decanter is not a filter, it is a device that separates water from fuel.
- The engine should never run with the decanter water level over half, as engine damage may occur.

DANGER



- This must be carried out with the engine cold and switched off.
- As fuel is very flammable, keep open flames away from it and do not smoke during this operation.
- Clean up any area affected by spilled fuel immediately.
- During this operation, wear protective clothing.

ATTENTION




DO NOT use the starter motor to turn over the engine in order to prime the fuel system. This can cause the starter motor to overheat and damage the coils, the pinion and/or the crown gear.

Drain the decanter whenever contaminants, such as water, collect at the bottom of the cup. There is a red float ring in the bowl that rises with the level of water to indicate how much needs to be drained.

Proceed as follows to drain the fuel separator:

1. Open the drain plug **(A)**. Collect the drained liquid in a suitable container. Properly dispose of drained fluid.
2. Close the drain plug **(A)** using only manual pressure.



9.5.7 - REPLACING THE FUEL DECANter CARTRIDGE

ATTENTION

- The cartridge must be replaced *every 500 hours or 1 year*.
- When contaminants appear, remove them immediately, **DO NOT** wait for scheduled maintenance to be carried out.

DANGER

- In certain specific conditions, diesel is flammable and explosive.
- Never use diesel as a cleaning agent.
- When a component is removed from the fuel supply system to carry out maintenance (e.g. to replace the fuel filter), place an approved container under the opening to collect the fuel.
- Do not use rags to collect the fuel. The vapours from the rags are flammable and explosive.
- Clean up any area affected by spilled fuel immediately.
- Wear eye protection. The fuel supply system is pressurised and the fuel could spurt out when any of the components are removed.
- Lack of caution may cause death or serious injury.
- This must be carried out with the engine cold and switched off.
- As fuel is very flammable, keep open flames away from it and do not smoke during this operation.

ATTENTION


DO NOT use the starter motor to turn over the engine in order to prime the fuel system. This can cause the starter motor to overheat and damage the coils, the pinion and/or the crown gear.

WARNING

- If the separator and/or the filter inside it are damaged, they should be replaced immediately.
- Observe the regulations in force in the country of use for the correct disposal of hazardous material, such as engine oil, diesel and engine coolant. Contact local authorities or a recycling centre.
- Never dispose of hazardous material irresponsibly by pouring it down drains, on the ground or into groundwater or waterways.
- Failure to observe these procedures could cause serious damage to the environment.

1. Place a suitable container under the decanter to collect fuel that may leak. Clean the spilled fuel and the outer body of the filter unit.
2. Open the drain valve (F) and the vent screw (A) to drain the filter. Close the drain screw and the vent screw. Use only manual pressure to tighten the drain screw and vent screw.
3. Remove the filter cup (E) and remove the filter element (C) from the filter (B). Remove the used filter element (C).
4. Remove and discard the O-ring gasket (D).
5. Make sure all components are clean and dry.
6. Install a new O-ring gasket (D) and install a new filter element (C).
7. Install the filter cup (E) on the filter (B) and tighten the filter cup to a maximum torque of 10 Nm.

8. The secondary filter element must be replaced at the same time as the primary filter element.



9.5.8 - DRAINAGE AND VENTING OF THE FUEL FILTER


ATTENTION

Drainage and venting of the fuel filter should be done *every 8 hours or daily*.

DANGER

- Leakage or spillage of fuel onto hot surfaces or electrical components can result in a fire.
- To avoid possible injury, turn off the starter switch when changing fuel filters or water separator elements.
- Clean up fuel spills immediately.

1. Place a suitable container under the filter. Open the drain valve (A) and drain the liquid.
2. If necessary, close the drain valve (A) only with hand pressure.



9.5.9 - REPLACING THE FUEL FILTER

ATTENTION



The replacement of the fuel filter must be carried out *every 500 hours or 1 year*.

DANGER



- In some conditions specific to diesel fuel and flammable and explosive.
- Never use diesel as a cleaning agent.
- When a component is removed from the fuel supply system to carry out maintenance (e.g. to replace the fuel filter), place an approved container under the opening to collect the fuel.
- Do not use rags to collect the fuel. The vapours from the rags are flammable and explosive.
- Clean up any area affected by spilled fuel immediately.
- Wear protective goggles. The fuel supply system is pressurised and the fuel could spurt out when any of the components are removed.
- Lack of caution may cause death or serious injury.
- This must be carried out with the engine cold and switched off.
- As fuel is very flammable, keep open flames away from it and do not smoke during this operation.

ATTENTION



DO NOT use the starter motor to turn over the engine in order to prime the fuel system. This can cause the starter motor to overheat and damage the coils, the pinion and/or the crown gear.


WARNING



- If the separator and/or the filter inside it are damaged, they should be replaced immediately.
- Observe the regulations in force in the country of use for the correct disposal of hazardous material, such as engine oil, diesel and engine coolant. Contact local authorities or a recycling centre.
- Never dispose of hazardous material irresponsibly by pouring it down drains, on the ground or into groundwater or waterways.
- Failure to observe these procedures could cause serious damage to the environment.

1. Turn the fuel supply valve (if equipped) to the OFF position before performing maintenance.
2. Place a suitable container under the filter to collect fuel that may leak. Clean the outer body of the filter unit.
3. Use a suitable tape wrench to remove the filter cup (E) from the filter base (B).
4. Remove the filter element (C). Remove the sealing O-ring (D) from the cup (E). Remove the gasket (G) from the discharge valve (F). Replace the gasket (G)
5. Install the new filter element (C) in the filter base (B).
6. Install a new O-ring gasket (D) on the filter cup (E). Make sure the filter cup (E) is clean. Install the latter on the base of the filter (B). Do not use any tools to install the filter assembly. Use only hand pressure to tighten the filter cup.

7. The primary fuel filter and the secondary fuel filter must be replaced at the same time.



9.5.10 - CLEANING OR REPLACING AIR FILTERS

ATTENTION



- The filters should be cleaned *daily*.
- The cartridges of the air filter unit should be replaced *every 500 working hours*.

DANGER




- Dismantle the air filter only when the engine is stopped and do not start the engine with the air filter open.
- During cleaning wear appropriate protective clothing.

ATTENTION




- Do not wash the air filter elements.
- Do not use solvents.
- Do not grease the cartridges.
- If cleaning with compressed air, take care how to you direct the air jet to avoid damaging the filter cartridge. The air jet should always be directed from the inside of the cartridge outward. If you do the opposite, the filter will become ineffective and will release the dust into the extraction system when the engine is running, thus damaging the motor.



WARNING




- The air filter group consists of a primary high-capacity cartridge and a safety cartridge.
- The primary cartridge can be cleaned with a jet of air, but the safety cartridge must only be replaced.
- Each time the primary cartridge is replaced, the safety cartridge must be replaced too.



To clean/replace the air filter unit cartridge:

1. Detach the two rubber stay rods (B) securing the bonnet (A).
2. Pull the locking pin (C), raise the bonnet, then block it by releasing the pin.





3. Release the two catches and remove the cover (D).
4. Pull the primary cartridge (E) out. If it is difficult to remove, turn the cartridge slightly whilst pulling it at the same time. Clean it with a jet of air or replace it.
5. Pull the safety cartridge (F). If the extraction of the cartridge is difficult, make small rotation movements and at the same time pull the cartridge. Replace the safety cartridge every time the primary cartridge is changed.
6. Put the cover back on and fasten it with the two catches.

9.5.11 - CLEANING THE RADIATOR CASING AND THE RADIATOR

ATTENTION



Cleaning the radiator casing and the radiator should be done *daily* or *every 8 working hours*.



The radiator casing (A) should be cleaned both internally and externally. Clean with a jet of compressed air or with special products following the instructions on the containers of the products. Having completed the operations, dry the washed parts.

For greater efficiency of the cooling system, in addition to cleaning with a reversible fan (see "6.3.19 Reversible fan"), it is advisable to clean the radiator from any remaining traces of dust. To clean the radiator, lift the radiator casing (A) and clean the outside of the radiator (B) with a jet of compressed air or with specific products, following the instructions indicated on the product packaging. Having completed the operations, dry the washed parts. Close the radiator casing (A).

Clean the grilles (C) on both sides.

The sensor installed on the engine that detects the coolant temperature has three trigger thresholds:

1. At 95°C, the Robocut T500 emits an audible and a visual alarm signal on the display;
2. At 100°C, once this temperature is reached on the Robocut T500, the hydraulic motor of the equipment is stopped;
3. At 105°C, the heat engine of the Robocut T500 is stopped.

WARNING



If the engine temperature exceeds the maximum limit, the relative symbol appears on the display and the hydraulic motor of the tool is disabled.

9.5.12 - V-BELT INSPECTION / TENSIONING


ATTENTION

- The first check of the V-belt must be carried out *after the first 40 hours* of work of the machine.
- Subsequent checks are to be carried out *every 250 hours* of work.

To maximize engine performance, inspect the belt for wear and to check for cracks. Replace a worn or damaged belt.

To check the tension of the timing belt, proceed as follows:

1. Switch the machine off.
2. Wait for the engine to cool down.
3. Open the bonnet with the appropriate key supplied with the machine.
4. Check the belt tension (A): press the belt at the indicated point (X);



The correct tension for a new belt is between 400 and 489 N; the correct tension for a used belt that has been in operation for 30 minutes or more at rated speed is between 267 and 356 N.


If the belt tension is correct, skip to step 8 of the following section; if not, move onto the next step;

If the belt is too loose, vibrations may occur that are not necessary for the wear of the belt and pulleys. A loose belt could slip enough to cause overheating.

The belt tension must be checked at the central point of the belt between the pulleys.

To tighten the belt proceed as follows:


1. Loosen the bolt (A) and loosen the bolt (C).
2. Loosen nut and bolt (D).
3. Move the alternator (B) to adjust the belt (E) to the required voltage.
4. Tighten bolt (A) and bolt (C) to a torque of 22 Nm.
5. Tighten the nut and bolt (D) with a torque of 22 Nm.



If, during the inspection you notice that:

- There is not enough distance (**Z**) between the belt and the lower section of the pulley groove (see photo below);
- The belt is cracked / split;
- The belt is oily;

proceed with the belt replacement.



9.5.13 - REPLACING THE V-BELT



ATTENTION



Replacement of the V-belt must be carried out every 1000 hours.

To remove the timing belt, proceed as follows:

1. Switch the machine off.
2. Open the right-hand bonnet with the relevant spanner supplied with the machine.
3. Loosen the bolt (A) and bolt (B) on the adjustment bracket (I).
4. Loosen the nut (D) and bolt (E).
5. Push the alternator (3) towards the motor and remove the alternator belt (6).



To mount a new timing belt, proceed as follows:

6. Place the belt (F) on the alternator (C), the water pump pulley (G) and the crankshaft pulley (H). Make sure that the belt is correctly positioned on the pulleys.
7. Slide the alternator on the adjustment bracket (I) away from the motor to tighten the belt to the correct tension. The tension of a new belt is between 400 and 489 N.
8. Tighten the bolt (A), bolt (B) with a torque of 25 Nm.
9. Tighten the nut (D) and bolt (E) with a torque of 25 Nm.
10. Close the right side bonnet with the appropriate key.

WARNING



When mounting a new belt, check the tension again *after 20 hours* of motor operation.

9.5.14 - REPLACING THE CASING VENT FILTER

ATTENTION



The replacement of the casing vent filter must be carried out *every 1500 hours*.

DANGER



Oil and hot components can cause damage and/or injury. Avoid contact with the skin.

ATTENTION



- Make sure the engine is switched off before any maintenance or repairs.
- Care must be taken to ensure that liquids are contained during the performance of inspections, maintenance, testing, adjustments and repairs.
- Prepare to collect the fluid with suitable containers before opening any compartment or disassembling any fluid-containing components.

WARNING



- Dispose of all fluids according to local regulations.
- The casing vent is critical to engine maintenance emissions compliance.
- The filter element inside the casing vent must be checked within the prescribed review intervals.
- The filter element must be correctly mounted before starting the engine.
- Mounting the filter element is essential for the proper operation of the engine.
- The quality of the installed filter element is very important, Perkins recommends using the original Perkins Filters.
- The filter element protects the engine from excessive amounts of oil at the inlet of the induction system. The filter element also protects the engine after-treatment system.

ATTENTION



Excessive amounts of oil entering the engine induction system can quickly increase the engine speed without control.

To replace the casing vent filter proceed as follows:

1. Ensure dirt cannot enter the vent assembly. Ensure that the outer body of the vent assembly is clean and free of damage. Place a container under the vent assembly.
2. Trace temporary marks on the tube (**D**) to identify the correct orientation for mounting purposes.

ATTENTION




A one-way valve is installed in the tube, incorrect installation of the tube can cause serious damage to the motor.

3. Remove the hose clamp (C) and remove the hose (D) from the cap (B). Untighten the cup (B) from the main body (A).
4. Remove and discard the filter (E) and the O-ring (F).

ATTENTION



Make sure all parts are clean and free of dirt and damage.




5. Apply clean engine oil to the new O-ring (F) and place it on the cap (B).
6. Insert a new filter (E) into the cap (B).
7. Screw the cap into the main body (A) with a tightening of 10 Nm.
8. Insert the hose (D) and hose clamp (C). Make sure the hose is oriented correctly. If a new hose is installed, the end of the hose with the white band in position (X) must be fixed to the casing vent.

ATTENTION


Incorrect installation of the pipe can cause serious damage to the engine.

9. Remove the container and clean any traces of fluid.



9.6 - HYDRAULIC SYSTEM MAINTENANCE

9.6.1 - HYDRAULIC OIL LEVEL CHECK

ATTENTION



Check the hydraulic oil level every *8 working hours* or *daily*.

WARNING



- Do not top up oil beyond the MAX level, this could cause oil to leak from the tank.
- Restore the level only with hydraulic oil indicated in the table (see "9.4.1 Lubricants table").
- When using biodegradable oil Panolin HLP Synth E, avoid mixing it with other oils.
- The use of non-recommended lubricants and/or greases will result in invalidity of the warranty.

DANGER





When topping up, wear protective clothing.

The hydraulic oil check must be done on the flat.

The hydraulic oil level is correct when it reaches the mark on the dipstick attached to the filler cap.

To check the oil level:

1. Unscrew the cap (**A**) and check the oil level on it.
2. If the level of oil is low, top it up until it reaches the mark.
3. Close the cap tightly.



9.6.2 - CHANGING THE HYDRAULIC OIL FILTER

ATTENTION



- Quantity required for filling: 11 litres (approx).
- The hydraulic oil should be replaced as follows:

Type	Supplier	Replacement within
Mineral	Q8 HELLER 46	1000 hours
Biodegradable	PANOLIN HLP SYNTH E 46	15000 hours

DANGER




- It should be replaced with the machine is switched off, the equipment resting on the ground and when the hydraulic oil is cold.
- The machine should be parked on firm ground on the flat to ensure that the operations are carried out safely.

ATTENTION



- Always change the oil with the same type that was removed.
- Do not mix different types of oil.


To ensure correct lubrication and viscosity in the hydraulic pumps, it is necessary to replace the hydraulic oil at regular intervals. Refer to the following table for the frequency and type of oil to be used.



To change the oil proceed as follows:

1. Stop the machine on a level surface and raised off the ground in order to be able to carry out the operations safely.
2. Remove the front bottom guard (A) by unscrewing the six screws indicated in red. It is recommended to clean all the parts thoroughly before draining the oil from the tank.
3. Open the filler cap of the tank (C);
4. Remove the drain plug (B) from the tank using a 10 mm Allen key, being careful to collect the used oil in a container that has a capacity of at least thirty litres.

5. Tighten the cap (**B**) at the end of the operation and replace the copper washer, if necessary.
6. Add new hydraulic oil; refer the table above for the choice of oil.
7. Check the level on the dipstick attached to the filler cap (**C**).
8. As soon as the correct oil level is reached (see "**9.6.1 Hydraulic oil level check**"), start the engine and leave it running for ten seconds; repeat the operation until the supercharging pressure (20÷22 bar) on the pumps is reached.
9. Turn the engine off again and recheck the oil level.
10. If necessary, top up the oil pressure until the relative level lies between maximum and minimum.



9.6.3 - CHANGING THE HYDRAULIC OIL FILTER


ATTENTION



the hydraulic oil filter should be replaced *every 250 working hours* or when the clogging indicator light (A) is displayed.

To replace it, perform the following operations:

1. Unscrew the cap (B) using a 32-mm spanner.
2. Extract the filtering element (C);
3. Filters should only be replaced with original filters and before they become completely clogged.
4. Always check the O-ring and seals when a component of the hydraulic circuit is dismantled or is replaced. If broken or damaged, replace them.
5. Close the cap again and tighten it with the spanner with a maximum torque of 20 Nm.



9.7 - MAINTENANCE OF THE HYDRAULIC MOTORS AND HYDRAULIC VALVES

Periodically check that:

- There are hydraulic motor and hydraulic oil leaks. If there are try tightening the fixing screws.
- The hydraulic fittings connected to the motor and valves are not loose. If they are, tighten them.
- If the problem persists, contact the McConnel Support Service.

DANGER

- **At operating temperature, the hydraulic oil is boiling and at times also pressurised.**
- **Avoid skin contact with the boiling oil and with its pipelines.**

9.8 - MAINTENANCE OF THE ELECTRICAL SYSTEM



ATTENTION



- The electrical system should be checked *every 250 working hours*.
- If the cables show signs of a short circuit, look for the causes and contact the McConnel customer care department.

This is a visual inspection that must be carried out with the utmost care in order to avoid short-circuits in the system that would damage the machine. Check specifically:

- Fuses, if corroded or rusty, replace them with fuses of the same capacity.
- Batteries (**B**), check the battery clamp connections. If they are oxidised, remove the oxidation and coat them with appropriate grease. When carrying out this operation, be very careful not to let the earth wire (black) touch the power supply wire (red).
- Starter engine, check the cables.
- Alternator, check the cables.
- Check the tightening of the connectors.
- Check the tension of the distribution belt (**A**), (see "9.5.12 Check / tensioning of the V-belt").
- Checking the battery charge (**B**).



9.8.1 - CHECKING THE BATTERY CHARGE




ATTENTION



Battery charge should be checked every 250 hours.

To check the charge of the batteries:

1. Turn the machine off;
2. Open the right lower side bonnet (A) of the Robocut T500.
3. On the right side of the Robocut T500, locate the junction node box (B) of the positive line that comes directly from the batteries;
4. Check the voltage of the batteries with a multimeter (tester) by connecting the red tip to the junction node (B) and the black tip to the machine ground (C) (for example: to the machine frame or motor).




ATTENTION



If the voltage of the batteries with the engine switched off is sufficient (at least 12 - 12.5 Volts), but the machine does not start, **DO NOT CONTINUE** and proceed as indicated below.

5. Loosen the four screws which secure the battery cover.
6. Remove the battery (D);
7. Repeat steps 5 and 6 for the battery on the other side.



8. Check the voltage of each battery using a multimeter (tester) by connecting the red test lead to the positive terminal and the black test lead to the negative terminal. If either or both batteries are discharged, recharge them. In the event that, after the charging process of the latter, the start-up of the Robocut T500 is difficult to proceed with their replacement.
9. Insert the batteries.
10. Assemble the covers, then tighten the four screws.

Furthermore, make sure that:

- Do not carry out any modifications to the electrical system without the prior authorisation of McConnel.
- Do not eliminate or install any components without the prior authorisation of McConnel.
- Avoid contact of the electrical system with water.
- Protect the connection pins with corrosion inhibitors.

DANGER



- **Never check the battery charge status by connecting the two poles with a metal object, use the voltmeter.**
- **Always disconnect the earth connector (—) of the battery first and reconnect it last.**
- **The sulphuric acid in the battery electrolyte is poisonous. It can cause burns to the skin get through fabrics and cause blindness if it comes into contact with the eyes.**
- **It should be noted that its compounds cause cancer and other harm to the reproductive organs. These substances are present in the battery poles, terminals and relative accessories. Wash your hands after touching them.**

9.9 - WHEEL DRIVE MAINTENANCE


9.9.1 - CHECKING THE TIGHTNESS OF THE SCREWS

ATTENTION




The screws should be tightened every 250 working hours.

The check must be carried out using a torque wrench. Refer to the table below for the required tightening torques. This should be carried out on both sides of the machine.



Nut size	M14
Spanner	21 mm
Tightening torque	250 ± 25 Nm



Screw size	M12
Allen key	10 mm
Tightening torque	79 Nm

9.10 - TRACK MAINTENANCE

9.10.1 - CHECKING THE TRACK TENSION PRESSURE

ATTENTION



Track tensioning should be performed *every 40 hours or weekly*.

DANGER




- The pressure test must be carried out with the utmost care because it is performed in a zone in which there can be a very high pressure.
- **NEVER WORK DIRECTLY ON THE VALVE WITH YOUR HANDS. IF THE VALVE IS BLOCKED OR DAMAGED, CONTACT AN McConnel SERVICE CENTRE.**
- Do not attempt to unblock the valve. Extremely dangerous pressures may have built up inside the valve.

ATTENTION



It is also recommended to recheck the tensioning after *8 / 10 hours* of operation and set it to the values indicated in the table above.

This check should be carried out to preserve the tracks, keep them in perfect working order and to prevent the tracks from accidentally slipping out of position.



To check the pressure:

1. Position the machine on a level surface.
2. Remove the cover (A).
3. Place the nozzle of the pump (C) onto the grease valve (B); check the pressure on the pressure gauge when injecting grease. Refer to the following table for the pressures of the tracks.
4. Replace the cover (A).

Track tightening pressure	
Track	Max. pressure (bar)
Rubber 250	150
Rubber 280	150

Use a lever grease gun having the following characteristics to tension the track:

Filling capacity	500 cm ³
Filling type	400 g (cartridge)
Delivery / stroke volume	1.2 cm ³
Delivery pressure (max)	400 bar
System pressure (max)	850 bar
Gauge pressure (max)	250 bar



9.10.2 - REPLACING THE TRACK

DANGER



- The machine support must be capable of supporting the load and keep it in a stable and safe position.
- To lift the machine, refer to chapter 7.

ATTENTION




It is also recommended to recheck the tensioning after 8 / 10 hours of operation and set it to the values indicated in the table above.

Tracks should be replaced when only 10 mm of tread is left, or before if they show signs of cuts.

Proceed as follows:

1. Place the machine on level ground with the engine switched off and raised (30 - 40 cm) off the ground.
2. Thoroughly clean the parts of the undercarriage.
3. Remove the cover (A) from the side member.
4. Slowly loosen the tensioning valve (B) using a 27 mm wrench in order to drain the grease.
5. Remove the tensioning valve only when there is no longer any pressure and the track is completely loose.
6. Move the front wheel backwards using a rubber hammer.
7. Lift the lower half of the track.
8. Move the track out from its seat (outwards) by levering it off from the idle wheel.
9. To install the new track follow the instructions above in reverse order.
10. The correct track tension is obtained by using the tensioning kit, pumping grease until the maximum pressure is reached (see "9.10.1 Track tension pressure check").



9.10.3 - ROLLER WEAR CHECK

The rollers are considered wear parts. Their duration depends on the ground on which they operate (muddy, sandy or other types).

An average life of 500 working hours is estimated, which obviously depends on the working conditions in which the machine is used.

ATTENTION

It is recommended that you check a roller (by removing it) as soon as you realise that it doesn't rotate freely and establish the reason for it.

9.11 - MACHINE GREASING

All machine moving parts that need to be greased are equipped with special greasers. Refer to the grease table in paragraph "9.4.1 Lubricant table" for grease selection. Proper lubrication is very important. Insufficient and infrequent lubrication may cause premature faults or overheating in some of the working parts as well as damage to the gaskets.

9.11.1 - LIFTING DEVICE


WARNING



Grease the lifting device every *8 hours of use or daily*.

To grease the machine you must:

1. have an appropriate pump.
2. Connect the pump nozzle to a grease nipple.
3. Pump in grease into it until a small amount seeps out from the joints.
4. Repeat the procedure on the other three points of the lift.



9.11.2 - CHECKING THE CHROME-PLATED PARTS

ATTENTION

Inspect the chrome-plated parts of the machine (cylinders) and make sure that they are not scored or damaged *every 40 working hours or weekly.*

9.12 - PERIODICAL REPLACEMENT OF THE SAFETY COMPONENTS

To guarantee safety at all times while the machine is being used, the operator is required to replace the components listed below:

Periodical replacement of the safety components		
Component	Years	Hours
Fuel pipes	2	2000
Hydraulic pipes	4	4000

9.13 - MAINTENANCE OPERATIONS
9.13.1 - MAINTENANCE FREQUENCY

		Every 8 hours / daily	Every 40 hours / weekly	250 hours	500 hours	750 hours	1000 hours	1250 hours	1500 hours	1750 hours	2000 hours	2250 hours	2500 hours	2750 hours	3000 hours
ENGINE OIL	Check / Top up	X													
	Replacement				X		X		X		X		X		X
ENGINE OIL FILTER	Replacement			X		X		X		X		X		X	
LIQUID COOLANT	Check / Top up	X													
	Replacement														X
FUEL	Check / Top up	X													
FILTER FUEL	Drainage	X													
	Replacement				X		X		X		X		X		X
FUEL SEPARATOR	Check / Drain	X													
FUEL SEPARATOR CARTRIDGE	Replacement				X		X		X		X		X		X
ENGINE AIR FILTER	Check / Clean	X													
	Replacement				X		X		X		X		X		X
CASING VENT FILTER	Replacement								X						X
RADIATOR CASING	Clean	X													
RADIATOR	Clean	X													
ELECTRIC PLANT	Check			X	X	X	X	X	X	X	X	X	X	X	X
BATTERY	Check			X	X	X	X	X	X	X	X	X	X	X	X
V-BELT	Tensioning		X^(b)	X	X	X	X	X	X	X	X	X	X	X	X
	Replacement						X				X				X
HYDRAULIC OIL	Check / Top up	X													
	Replacement						X^(a)				X^(a)				X^(a)
HYDRAULIC OIL FILTER	Replacement			X	X	X	X	X	X	X	X	X	X	X	X
TENSIONING TRACKS	Check		X												
RETAINER MONOWHEEL	Check			X	X	X	X	X	X	X	X	X	X	X	X
LIFTING DEVICE	Greasing	X													

^(a) Change according to the type of hydraulic oil in the machine. (Refer to the tables in sections 9.4.1 and 9.6.2).

^(b) To be performed only for the first check / replacement.

		Every 8 hours / daily	Every 40 hours / weekly	250 hours	500 hours	750 hours	1000 hours	1250 hours	1500 hours	1750 hours	2000 hours	2250 hours	2500 hours	2750 hours	3000 hours
CHROME-PLATED PARTS	Check		X												
(a) Change according to the type of hydraulic oil in the machine. (Refer to the tables in sections 9.4.1 and 9.6.2).															
(b) To be performed only for the first check / replacement.															

10 - INSTRUCTIONS FOR EMERGENCY SITUATIONS

10.1 - FIRE

In case of fire, use a fire extinguisher according to the standards in force. If the machine catches fire or it is close to a fire, raise the alarm and contact the fire service.

10.2 - ASSISTING THE OPERATOR IN CASE OF ILLNESS

If the operator feels unwell, you need to act quickly, following the steps indicated below:

- Get to the operator, if you are unable to do so safely, contact medical or first aid personnel.
- Lay the operator on the ground following first aid procedures.
- Contact a doctor or the emergency services if you have not already done so.

10.3 - MANUAL BRAKE RELEASE & TOWING

Parking Brake Release

During operation or transport, situations may arise when it may be necessary to tow the machine. Before attempting to tow the machine the parking brake must be manually released to reduce the possibility of damage to the drive motor, tracks, or braking systems, and provide safe towing.

The procedure of releasing the brakes requires access to the brake flange plate at the back of the drive motor and utilisation of the following items; a 12mm bolt, a 12mm nut and a support plate with a central hole. The method of release is described below;

⚠ WARNING

Ensure machines tracks are safely and securely 'chocked' before attempting to release the brakes.

Remove the 4 bolts which retain the cover to the drive motor housing to gain access to the brake assembly on the back of the drive motor.



Pry the rubber dust cover from the brake release access hole.



With nut and support plate on the 12mm bolt; thread the bolt into the manual brake release hole until it 'bottoms out' in the hole. Move the washer down the shank of the bolt and thread the nut down until it is in firm contact with the metal support plate. Tightening the nut will gradually draw the bolt out and pull the brake plates away releasing the brakes. Turn the nut until it tightens against the plate and will no longer turn. Stop when resistance prevents further movement, **do not over-tighten**.



10.4 - TOWING

⚠ CAUTION

Towing of the machine should only be performed in an emergency situation; it should be avoided whenever possible.

Manually release the braking system before attempting to tow the machine; see *previous page* for details of this procedure.

Suitable towing straps or chains rated to **minimum 2 tonne** and free from damage or defects must be used to tow the machine. Towing equipment should be configured as shown in the illustration opposite.

A. Towing strap/chain with minimum 2 tonne rating.

B. Rigid link device with minimum 2 tonne rating.

Attach the straps/chains to the lifting point positions on each side of the machine. Tow the machine maintaining even pull on each side in a forward direction. Avoid towing the machine from one side or the other as this can risk damaging the tracks and/or track components.

⚠ WARNING


When towing the machines on downward inclines suitable rigid towing equipment must be used.

⚠ WARNING

Care must be adopted at all times when towing the machine as there will be no form of braking. Chock tracks to avoid risk of 'freewheeling'. Keep all persons clear of the front and rear of the machine when parking brakes have been manually released.

⚠ WARNING

When towing or lifting the machine the correct attachment points must be used, failure to observe this may result in serious damage to machine and/or injury to persons.



11 - TIGHTENING TABLES

11.1 - SCREW TIGHTENING TABLE

Threading nominal size	Actual section area As mm ²	Strength class								
		12.9			10.9			8.8		
		Breaking load	Initial tightening force	Tightening torque	Breaking load	Initial tightening force	Tightening torque	Breaking load	Initial tightening force	Tightening torque
		N	N	Nm	N	N	Nm	N	N	Nm
M 3×0.5	5.03	5523	3865	2	4728	3316	1	3218	2256	1
M 4×0.7	8.78	9643	6749	4	8260	5778	3	5621	3934	2
M 5×0.8	14.2	15597	10918	8	13361	9349	7	9094	6367	5
M 6×1	20.1	22082	15460	14	18914	13234	12	12881	9015	8
M 8×1.25	36.6	40211	28144	33	34433	24103	28	23446	16412	19
M 10×1.5	58	63725	44606	65	54563	38200	56	37150	26006	38
M 12×1.75	84.3	92626	64834	114	79304	55515	97	54004	37798	66
M 14×2	115	126352	88446	181	108194	75733	155	73673	51571	105
M 16×2	157	172499	118102	282	147699	103388	241	100572	70397	164
M 18×2.5	192	210954	147669	387	180632	126441	332	126765	88731	232
M 20×2.5	245	269186	18843	549	230496	161345	470	161757	113227	330
M 22×2.5	303	332912	233036	748	285059	199535	640	200046	140028	449
M 24×3	353	387848	271491	950	332098	232468	813	233056	163140	571

11.2 - FITTINGS TIGHTENING TABLE

Series	Ø Pipe	THREADING - TIGHTENING TORQUE					
		Ø Threaded Gas	Shape B MT (Nm)	Shape E MT (Nm)	Ø Metric thread	Shape B MT (Nm)	Shape E MT (Nm)
Light	6	G 1/8"	25	20	M 10 x 1	25	20
	8	G 1/4"	45	40	M 12 x 1.5	30	30
	10	G 1/4"	45	40	M 14 x 1.5	50	50
	12	G 3/8"	85	80	M 16 x 1.5	80	60
	15	G 1/2"	160	100	M 18 x 1.5	90	80
	18	G 1/2"	105	100	M 22 x 1.5	150	140
	22	G 3/4"	230	200	M 26 x 1.5	240	200
	28	G 1"	390	380	M 33 x 2	400	380
	35	G 1" 1/4	600	500	M 42 x 2	600	500
	42	G 1" 1/2	800	600	M 48 x 2	800	600
Strong	6	G 1/4"	60	60	M 12 x 1.5	45	45
	8	G 1/4"	60	60	M 14 x 1.5	60	60
	10	G 3/8"	110	90	M 16 x 1.5	95	80
	12	G 3/8"	110	90	M 18 x 1.5	120	100
	14	G 1/2"	170	130	M 20 x 1.5	170	140
	16	G 1/2"	140	130	M 22 x 1.5	190	150
	20	G 3/4"	320	200	M 27 x 2	320	200
	25	G 1"	390	380	M 33 x 2	450	380
	30	G 1" 1/4	600	500	M 42 x 2	600	500
	38	G 1" 1/2	800	600	M 48 x 2	800	600

12 - NOTES



McConnel Limited, Temeside Works, Ludlow, Shropshire SY8 1JL. England.
Telephone: 01584 873131. Facsimile: 01584 876463. www.mcconnel.com