

ROBOPOWER

Parts Manual

For Machines S/No: ROBOP091500007 ▶




CONTENTS

Chassis Assembly	1
Engine Accessories	3
Engine & Filters	5
Coupler Assembly	7
Pump Assemblies	9
Engine Mountings	11
Oil Tank Assembly	13
Diesel Tank Assembly	15
Undercarriage Assembly	17
Drive Roller Assemblies	19
Control Valve	21
Hydraulic Components	23
Commutator Assembly	25
Radiator Assembly	27
QR Couplings	29
Electric Boxes	31
Side Casings – Left Hand	33
Side Casings – Right Hand	35
Upper Casings	37
Rear Casings	39
Lower Side Casings – Left Hand	41
Lower Side Casings – Right Hand	43
Diesel Fuel & Engine Oil Hoses	45
Radiator Hydraulic Hoses	47
Rear Lifting Device Hydraulics	49
Front Lifting Device Hydraulics	51
Hydraulic Pumps Circuit	53
Hydraulic Circuit Hoses	55
Rubber Tracks	57
Metal Tracks	59
Rear Linkage Assembly	61
Front Linkage Assembly	63
Rear PTO Assembly	65
Front PTO Assembly	67
Front PTO Selector	69
Safety Decals	71

CHASSIS ASSEMBLY

Machine: ROBOPOWER

McCONEL



CHASSIS ASSEMBLY**McCONNEL**


Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Chassis Assembly
1	1	4004001	FRAME
2	2	4004002	BRACKET (RIGHT)
3	1	4004003	BRACKET (LEFT)
4	2	4004004	BRACKET
5	1	4004005	SLEEVE
6	1	4004006	BRACKET
7	1	4004007	BRACKET
8	3	4004008	BOLT
9	7	4000415	WASHER
10	4	4000608	WASHER
11	3	4000758	WASHER
12	7	4005223	BOLT
13	3	7315559	WASHER
14	3	4000385	WASHER
15	1	4004009	SERIAL PLATE

ENGINE ACCESSORIES

Machine: ROBOPOWER


McCONEL



ENGINE ACCESSORIES**McCONNEL**

Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Engine Accessories
1	1	4004062	FLANGE
2	1	4004063	CLAMP
3	1	4004064	BRACKET
4	1	4004065	BRACKET
5	1	4004066	HOSE
6	1	4004067	HOSE
7	1	4004068	SILENCER
8	1	4004069	EXHAUST PIPE
9	2	4000806	BOLT
10	4	4004070	BOLT
11	1	4005216	RELAY
12	2	7315559	WASHER
13	2	4000385	WASHER
14	1	4004071	EXHAUST PIPE
15	11	4004072	COLLAR
16	1	4004073	EXHAUST PIPE
17	1	4004074	EXHAUST PIPE
18	8	4004075	BOLT
19	2	4004076	COLLAR
20	1	4004077	RAIN COVER
21	5	4004078	SLEEVE
22	1	4004079	PIPE
23	1	4004080	PIPE
24	1	4004081	CLAMP
25	1	4004082	FILTER HOUSING
26	1	4004083	PRE-FILTER
27	1	4004056	SECONDARY AIR FILTER
28	1	4004055	PRIMARY AIR FILTER
29	2	4004084	CLAMP
30	2	4004085	BOLT
31	2	4000385	WASHER
32	2	4004086	WASHER
33	2	4005223	BOLT
34	2	4005148	BOLT
35	1	4004087	COLLAR
36	1	4004088	COLLAR



ENGINE & FILTERS**McCONNEL**


Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Engine & Filters
1	1	4004100	ENGINE
2	1	4004089	OIL FILTER
3	1	4004090	FUEL PRE-FILTER
4	1	4004091	FUEL FILTER
5	1	4004092	BRACKET
6	4	4004093	CONNECTOR
7	3	4004094	BANJO BOLT
8	6	4004095	WASHER
9	4	4004096	BANJO BOLT
10	7	4004097	WASHER
11	2	4004008	BOLT
12	4	4000758	WASHER
13	2	4000756	LOCKNUT
14	2	4000415	WASHER
15	2	4004098	BANJO CONNECTION

COUPLER ASSEMBLY

Machine: ROBOPOWER

McCONNEL



COUPLER ASSEMBLY**McCONNEL**


Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Coupler Assembly
1	1	4004099	COUPLER
2	1	4004101	COVER PLATE
3	1	4004102	FLANGE
4	1	4004103	FLANGE
5	1	4004104	COUPLING
6	1	4004105	DRIVE COUPLING
7	1	4004106	DRIVE COUPLING
8	4	4004107	WASHER
9	8	4000211	BOLT

PUMP ASSEMBLIES

Machine: ROBOPOWER

McCONEL



PUMP ASSEMBLIES**McCONNEL**


Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Pump Assemblies
1	1	4004108	PUMP
2	1	4004109	PUMP
3	8	7315611	BOLT
4	2	4004110	CONNECTOR
5	2	4004111	ADAPTOR
6	4	4004112	BOLT
7	2	4004113	BOLT
8	1	4004114	ADAPTOR
9	16	4000415	WASHER
10	16	4004008	BOLT
11	4	4004107	WASHER
12	4	9100206	WASHER
13	1	4004115	PUMP
14	4	4004116	FLANGE HALF
15	1	4000760	WASHER
16	4	4004117	BOLT
17	1	4004118	O-RING
18	1	4004119	ADAPTOR
19	1	4004120	O-RING
20	2	4000681	BOLT
21	2	4004121	O-RING
22	2	4004122	FLANGE
23	2	7315611	BOLT
24	8	4000543	BOLT
25	1	4004123	PUMP
26	4	4001538	WASHER
27	8	4004124	FLANGE HALF
28	1	4004125	CONNECTOR


ENGINE MOUNTINGS

Machine: ROBOPOWER

McCONEL



A



11

ENGINE MOUNTINGS

McCONNEL


Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Engine Mountings
1	1	4004138	* BRACKET - Builds ► ROBOP091500010
	1	4004126	** BRACKET - Builds ROBOP091500011 ►
2	1	4004139	* BRACKET - Builds ► ROBOP091500010
	1	4004127	** BRACKET - Builds ROBOP091500011 ►
3	6	4004130	BOLT
4	6	4004131	WASHER
5	20	7315611	BOLT
6	14	4000751	LOCKNUT
7	32	4001535	WASHER
8	20	4000760	WASHER
9	1	4004138	* BRACKET - Builds ► ROBOP091500010
	1	4004128	** BRACKET - Builds ROBOP091500011 ►
10	1	4004139	* BRACKET - Builds ► ROBOP091500010
	1	4004129	** BRACKET - Builds ROBOP091500011 ►
11	8/6	4004132	*/** RUBBER MOUNT
12	8/6	4004133	*/** WASHER
13	8/6	4004134	*/** MOUNT BRACKET
14	8/6	4004135	*/** MOUNT BASE
15	1	4004136	MOUNT KIT (c/o items 11, 12, 13 & 14)

OIL TANK ASSEMBLY

Machine: ROBOPOWER

McCONEL



OIL TANK ASSEMBLY**McCONNEL**


Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Oil Tank Assembly
1	3	4004027	BOLT
2	3	4000610	WASHER
3	3	4004011	WASHER
4	1	4004028	TANK
5	1	7315589	FILLER
6	1	4004029	CLAMP BRACKET
7	1	4004030	CLAMP
8	1	4004031	ADAPTOR
9	1	4004032	ADAPTOR
10	1	4004033	FILTER SHIELD
11	1	4004034	OIL FILTER
12	1	7315766	CONNECTOR
13	1	4004137	DRAIN PLUG
14	1	4004035	OIL LEVEL WINDOW
15	2	4000148	SENSOR
16	6	9343032	BOLT
17	5	9414044	BOLT
18	4	7315894	BOLT
19	2	4000865	NUT
20	1	7315589	FILLER CAP
21	1	7315750	BOLT
22	1	9100104	WASHER

DIESEL TANK ASSEMBLY

Machine: ROBOPOWER

McCONEL



DIESEL TANK ASSEMBLY**McCONNEL**


Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Diesel Tank Assembly
1	2	4000175	BOLT
2	2	4000610	WASHER
3	4	4005038	WASHER
4	1	4000864	DRAIN PLUG
5	1	4004036	TANK
6	1	4000474	CAP
7	1	4004039	GUARD
8	2	4000789	WASHER
9	2	4005148	BOLT
10	1	4004038	SENSOR
11	1	4000221	NUT
12	2	4000791	NUT

UNDERCARRIAGE ASSEMBLY

Machine: ROBOPOWER

McCONEL



UNDERCARRIAGE ASSEMBLY

McCONNEL




Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Undercarriage
1	2	4004140	REDUCTION GEARBOX
2	2	4004141	SPROCKET
3	2	4004142	MOTOR
4	4	4000175	BOLT
5	40	4001537	WASHER
6	2	4004143	BRACKET
7	2	4004144	BRACKET
8	2	4004145	ROLLER
9	16	4004146	BOLT
10	16	4000451	NUT
11	20	4004147	NUT
12	20	4004148	WASHER
13	4	4000218	NUT
14	2	4004150	TENSIONER ASSEMBLY
15	36	4004052	BOLT
16	44	4000610	WASHER
17	4	4004053	BOLT
18	32	4001535	WASHER
19	2	4004149	VALVE
20	2	4004095	WASHER
21	2	4004151	SPACER
22	4	4000681	BOLT
23	2	4004152	TENSIONER UNIT c/o
24	1	4004153	NUT
25	1	4000427	COPPER WASHER
26	1	4004154	TENSIONER BODY
27	1	4004155	PRESSURE GAUGE
28	2	4004156	O-RING
29	1	4004157	RING
30	1	4004158	WASHER
31	2	4004338	TRACK TENSIONER KIT

DRIVE ROLLER ASSEMBLIES

Machine: ROBOPOWER

McCONEL



DRIVE ROLLER ASSEMBLIES**McCONNEL**



Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Drive Rollers
1	6	4004159	ROLLER ASSEMBLY
2	6	4004160	ROLLER BRACKET
3	12	4004161	ROLLER
4	24	4004162	BOLT
5	12	4004163	BUSH
6	6	4004164	PIN
7	6	7315629	WASHER
8	6	4004165	NUT
9	6	4000224	GREASE NIPPLE
10	4	4004145	ROLLER
11	8	4000175	BOLT
12	8	4001537	WASHER
13	8	4000610	WASHER

CONTROL VALVE

Machine: ROBOPOWER

McCONEL




CONTROL VALVE**McCONNEL**

Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Control Valve
1	1	4004166	CONTROL VALVE
2	2	4004167	CONNECTOR
3	14	7315777	CONNECTOR
4	2	7315797	CONNECTOR
5	2	4004168	COIL

Machine: ROBOPOWER




Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Hyd. Components
1	1	4004169	VALVE
2	1	4004170	CONNECTOR
3	1	4004171	CONNECTOR
4	1	4004172	CONNECTOR
5	1	4000546	CHECK COUPLING
6	2	4000581	SPACER
7	8	4000579	CONNECTOR
8	1	4001546	VALVE BLOCK
9	1	4004173	BRACKET
10	1	4004174	VALVE
11	2	4004175	BOLT
12	8	4000489	WASHER
13	4	4000791	NUT
14	2	4004176	BOLT
15	1	4004177	CONNECTOR

COMMUTATOR ASSEMBLY

Machine: ROBOPOWER

McCONEL



COMMUTATOR ASSEMBLY**McCONNEL**


Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Commutator
1	1	4004178	COMMUTATOR
2	1	4004179	VALVE BLOCK
3	1	7315775	CONNECTOR
4	7	4004180	CONNECTOR
5	1	7316041	ELBOW
6	1	4004181	CONNECTOR
7	1	4004182	SENSOR
8	1	4004183	VALVE
9	1	4004184	CONNECTOR

RADIATOR ASSEMBLY

Machine: ROBOPOWER

McCONNEL



RADIATOR ASSEMBLY**McCONNEL**




Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Radiator Assembly
1	1	4004185	RADIATOR
2	2	4004186	CONNECTOR
3	4	4004117	BOLT
4	4	4000865	NUT
5	1	9213084	BOLT
6	1	7315559	WASHER
7	1	4003021	WASHER
8	1	4004187	FAN MOTOR
9	2	7315797	CONNECTOR
10	2	4000209	BOLT
11	2	9100205	WASHER
12	6	4000608	WASHER
13	1	4004188	LEVEL SWITCH
14	2	9200082	BOLT
15	2	4000756	NUT
16	1	4000579	CONNECTOR
17	-	-	REQUEST AVAILABILITY
18	2	4004189	BRACKET
19	2	4004190	COLLAR

QR COUPLINGS

Machine: ROBOPOWER

McCONEL



QR COUPLINGS**McCONNEL**


Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - QR Couplings
1	1	4005036	NUT
2	1	4004191	FITTINGS PLATE
3	2	4004192	NUT
4	1	4004193	ADAPTOR
5	2	4004194	ADAPTOR
6	1	4004195	BONDED SEAL
7	2	4004196	BONDED SEAL
8	1	4004197	QR COUPLING
9	1	4004198	QR COUPLING
10	1	4004199	QR COUPLING
11	4	4000131	NUT
12	1	4004200	FITTINGS PLATE
13	1	4004201	FITTINGS PLATE
14	4	4004202	ADAPTOR
15	4	4000792	BONDED SEAL
16	4	4004203	QR COUPLING
17	4	4005222	BOLT
18	4	4001239	WASHER
19	1	4004204	PROTECTION PLATE
20	1	4004205	PROTECTION PLATE

ELECTRIC BOXES

Machine: ROBOPOWER

McCONNEL



ELECTRIC BOXES**McCONNEL**


Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Electric Boxes
1	1	4004222	COVER
2	2	4004223	BATTERY
3	1	4004224	BRACKET
4	9	4000353	BOLT
5	1	4004225	HOUSING
6	1	4004226	ELECTRICAL BOX
7	1	4004227	BRACKET
8	1	4004228	BRACKET
9	4	4004229	ANTI-VIBRATION
10	8	4000385	WASHER
11	3	4000865	NUT
12	3	4005223	BOLT
13	2	4000380	BOLT
14	1	4004230	BUNG
15	1	4004231	ISOLATOR SWITCH

SIDE CASINGS – LEFT HAND

Machine: ROBOPOWER

McCONNEL



SIDE CASINGS – LEFT HAND

McCONNEL


Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Side Casings LH
1	1	4004232	SIDE CASING ASSEMBLY F/LH
2	1	4004233	PANEL INSERT
3	1	4004234	CASING F/LH
4	35	4001229	NUT
5	2	4005071	LOCK
6	1	4004235	SIDE CASING ASSEMBLY R/LH
7	1	4004236	PANEL INSERT
8	1	4004237	CASING R/LH
9	3	4000321	WASHER
10	1	4004238	UNDER PANEL F/LH
11	1	4004239	UNDER PANEL R/LH
12	1	4004240	CASING FRAME R/LH
13	1	4004241	CASING FRAME F/LH
14	1	4004242	CENTRE PANEL LH
15	1	4004243	UPPER CASING F/LH
16	1	4004244	UPPER CASING R/LH
17	3	4004247	BOLT
18	4	4000385	WASHER
19	1	4004245	INSERT
20	1	4004246	CASING
21	3	4004248	BOLT

SIDE CASINGS – RIGHT HAND

Machine: ROBOPOWER

McCONNEL



SIDE CASINGS – RIGHT HAND

McCONNEL


Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Side Casings RH
1	1	4004252	SIDE CASING ASSEMBLY F/RH
2	1	4004233	PANEL INSERT
3	1	4004254	CASING F/RH
4	35	4001229	NUT
5	2	4005071	LOCK
6	1	4004255	SIDE CASING ASSEMBLY R/RH
7	1	4004236	PANEL INSERT
8	1	4004257	CASING R/RH
9	1	4004263	UPPER CASING F/RH
10	4	7315890	BOLT
11	10	4004253	NUT
12	1	4004260	CASING FRAME R/RH
13	1	4004261	CASING FRAME F/RH
14	1	4004262	CENTRE PANEL RH
15	1	4004258	UNDER PANEL F/RH
16	1	4004259	UNDER PANEL R/RH
17	1	4004264	UPPER CASING R/RH

UPPER CASINGS

Machine: ROBOPOWER

McCONNEL



UPPER CASINGS

McCONNEL


Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Upper Casings
1	18	4000385	WASHER
2	1	4004249	TOP CASING
3	1	4004250	TOP CASING INSERT
4	14	4005148	BOLT
5	14	4000321	WASHER
6	14	4000789	WASHER
7	14	4000791	NUT
8	2	4005071	LOCK
9	1	4004251	BONNET
10	1	4004256	GRILLE
11	1	4000430	BOLT
12	16	4004265	BOLT
13	4	4004266	LIGHT GUARD
14	6	4004267	TAB
15	1	4004268	CASING
16	3	4004054	HINGE
17	1	4004269	COVER PANEL
18	3	4004037	BOLT
19	3	4000544	WASHER
20	3	4000789	WASHER
21	3	9414044	BOLT
22	2	4004270	SPRING
23	1	4004271	NUT

REAR CASINGS

Machine: ROBOPOWER

McCONNEL



REAR CASINGS**McCONNEL**


Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Rear Casings
1	1	4004272	CASING
2	1	4004273	PANEL INSERT
3	12	4001229	NUT
4	1	4004274	CASING ASSEMBLY
5	1	4004275	BRACKET
6	1	4004276	GUARD
7	1	4004277	CASING

LOWER SIDE CASINGS – LEFT HAND

Machine: ROBOPOWER

McCONNEL



LOWER SIDE CASINGS – LEFT HAND**McCONNEL**


Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Lower Casings LH
1	1	4004278	CASING
2	1	4004279	CASING
3	1	4004280	CASING
4	1	4004281	MUDGUARD
5	1	4004282	CASING
6	1	4004283	CASING
7	1	4004051	CASING
8	1	4004047	MUDGUARD
9	1	4004284	MUDGUARD
10	1	4004285	CASING
11	1	4004286	MUDGUARD
12	1	4004046	CASING
13	2	7315559	WASHER
14	16	4005223	BOLT
15	16	4000385	WASHER
16	4	4004247	BOLT
17	1	4004287	CASING

LOWER SIDE CASINGS – RIGHT HAND

Machine: ROBOPOWER

McCONEL



LOWER SIDE CASINGS - RIGHT HAND**McCONNEL**


Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Lower Casings RH
1	1	4004040	CASING
2	1	4004041	CASING
3	1	4004042	CASING
4	1	4004043	CASING
5	1	4004044	CASING
6	1	4004045	MUDGUARD
7	1	4004046	CASING
8	1	4004047	MUDGUARD
9	1	4004048	MUDGUARD
10	1	4004049	CASING
11	1	4004050	MUDGUARD
12	1	4004051	CASING
13	2	7315559	WASHER
14	36	4005223	BOLT
15	4	4000385	WASHER
16	4	4004247	BOLT
17	1	4004288	CASING

DIESEL FUEL & ENGINE OIL HOSES

McCONNEL

Machine: ROBOPOWER



DIESEL FUEL & ENGINE OIL HOSES**McCONNEL**


Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Diesel & Oil Hoses
1	1	4004289	HOSE
2	1	4004290	HOSE
3	1	4004291	HOSE
4	1	4004292	HOSE
5	1	4004293	HOSE
6	1	4004294	HOSE
7	1	4004295	HOSE
8	3	4001247	JUBILEE CLIP

RADIATOR HYDRAULIC HOSES

Machine: ROBOPOWER

McCONNEL



RADIATOR HYDRAULIC HOSES




Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Radiator Hyd. Hoses
1	1	4004296	HOSE
2	1	4004297	HOSE

REAR LIFTING DEVICE HYDRAULICS

Machine: ROBOPOWER

McCONNEL



REAR LIFTING DEVICE HYDRAULICS



Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Rear Lifting Hydraulics
1	6	7315777	CONNECTOR
2	2	4000872	PLUG
3	2	4004298	BOLT
4	1	4004300	VALVE BLOCK

FRONT LIFTING DEVICE HYDRAULICS

Machine: ROBOPOWER

McCONNEL



FRONT LIFTING DEVICE HYDRAULICS




Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Front Lifting Hydraulics
1	6	7315777	CONNECTOR
2	2	4000872	PLUG
3	2	4004299	BOLT
4	1	4004300	VALVE BLOCK

HYDRAULIC PUMPS CIRCUIT

Machine: ROBOPOWER

McCONNEL



HYDRAULIC PUMPS CIRCUIT**McCONNEL**


Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Hydraulic Pumps Circuit
1	1	4004301	ELBOW ADAPTOR
2	1	4004170	CONNECTOR
3	1	4004169	VALVE
4	1	4004302	CONNECTOR
5	1	4000579	CONNECTOR
6	1	4004303	CONNECTOR
7	2	4000578	CONNECTOR
8	2	4004125	CONNECTOR

HYDRAULIC CIRCUIT HOSES

Machine: ROBOPOWER

McCONNEL



HYDRAULIC CIRCUIT HOSES




Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Hydraulic Circuit Hoses
1	1	4004304	HOSE
2	1	4004305	HOSE
3	1	4004306	HOSE
4	1	4004307	HOSE
5	1	4004308	HOSE
6	1	4004309	HOSE

RUBBER TRACKS

Machine: ROBOPOWER


McCONNEL



RUBBER TRACKS**McCONNEL**

Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Rubber Tracks
1	4	4004312	TRACK SHOE
2	8	4004313	BOLT
3	8	4001537	WASHER
4	8	4000610	WASHER
5	2	4004314	TRACK



METAL TRACKS**McCONNEL**


Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Metal Tracks
1	1	4004143	BRACKET
2	1	4004144	BRACKET
3	2	4004315	BRACKET
4	4	4004316	TRACK SHOE
5	2	4004320	METAL TRACK
6	2	4004145	ROLLER
7	8	4004146	BOLT
8	4	4000210	BOLT
9	4	4000175	BOLT
10	8	4004317	BOLT
11	4	4000758	WASHER
12	8	4001535	WASHER
13	12	4001537	WASHER
14	4	4000415	WASHER
15	8	4000760	WASHER
16	12	4000610	WASHER

REAR LINKAGE ASSEMBLY

Machine: ROBOPOWER

McCONNEL



REAR LINKAGE ASSEMBLY**McCONNEL**

Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Rear Linkage
1	1	4004206	HYDRAULIC RAM
2	1	4004207	HYDRAULIC RAM
3	2	4003018	PIN
4	2	7315619	PIN
5	1	4004208	MOUNTING PLATE
6	4	4000216	BOLT
7	2	4004209	LINK BALL
8	1	4004210	LINK ARM
9	1	4004211	LINK ARM
10	2	4004212	LINKAGE PIN
11	1	4004213	LINKAGE FRAME
12	4	4004214	BOLT
13	8	4004215	WASHER
14	4	4004216	NUT
15	1	7315884	LOCK PIN
16	4	4000544	WASHER
17	4	4000321	WASHER
18	4	4004037	BOLT
19	1	4004217	BRACKET
20	2	4004218	PTO GUARD PANEL
21	2	4004219	PTO GUARD PANEL
22	8	4000321	WASHER
23	8	4000791	LOCKNUT
24	8	4004334	BOLT
25	1	4004221	IDENTIFICATION PLATE
26	4	4004220	RIVET
27	2	7315777	CONNECTOR

FRONT LINKAGE ASSEMBLY

McCONNEL


Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Front Linkage
1	1	4004206	HYDRAULIC RAM
2	1	4004207	HYDRAULIC RAM
3	2	4002018	PIN
4	2	7315619	PIN
5	1	4004318	MOUNTING BRACKET
6	4	4000216	BOLT
7	2	4004209	LINK BALL
8	1	4004210	LINK ARM
9	1	4004211	LINK ARM
10	2	4004212	PIN
11	1	4004213	LINKAGE FRAME
12	4	4004214	BOLT
13	8	4004215	WASHER
14	4	4004216	NUT
15	1	7315884	LOCK PIN
16	4	4000544	WASHER
17	4	4000321	WASHER
18	4	4004037	BOLT
19	2	9100103	WASHER
20	1	4004319	MOUNTING PLATE
21	2	4004218	PTO GUARD PANEL
22	2	4004219	PTO GUARD PANEL
23	4	4004220	RIVET
24	1	4004221	IDENTIFICATION PLATE
25	1	4004321	COVER PLATE
26	12	4004322	BOLT
27	2	7315899	BOLT
28	12	4001638	WASHER
29	12	4001374	WASHER
30	2	9100203	WASHER

REAR PTO ASSEMBLY

Machine: ROBOPOWER

McCONEL



REAR PTO ASSEMBLY**McCONNEL**


Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Rear PTO Assembly
1	4	4004010	BOLT
2	8	4004011	WASHER
3	4	4004012	NUT
4	1	4004013	HOUSING
5	6	4000357	WASHER
6	6	4004014	BOLT
7	1	4004015	PLATE
8	4	4001535	WASHER
9	4	4000760	WASHER
10	4	4004016	BOLT
11	8	4004017	NUT
12	1	4004018	HOUSING
13	1	4004019	FLANGE
14	1	4004020	COUPLING
15	1	4004021	COUPLING
16	1	4004022	CIRCLIP
17	8	4004023	BOLT
18	1	4004024	COUPLING
19	2	4004025	COUPLING
20	1	4004026	COUPLING

FRONT PTO ASSEMBLY

Machine: ROBOPOWER

McCONEL



FRONT PTO ASSEMBLY**McCONNEL**


Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Front PTO Assembly
1	4	9343056	BOLT
2	6	4000357	WASHER
3	1	4004323	GEARBOX
4	2	4004324	BOLT
5	1	4004325	SPLIT FLANGE
6	1	4004326	MOTOR
7	8	4004146	BOLT
8	12	4000460	WASHER
9	4	4000479	WASHER
10	1	4004327	RING
11	8	4004328	BOLT
12	4	4001535	WASHER
13	1	4004329	BOLT
14	2	4001374	WASHER
15	2	4000370	WASHER
16	1	4004322	BOLT
17	1	4004330	PLATE
18	1	7316034	SHAFT GUARD

FRONT PTO SELECTOR

Machine: ROBOPOWER

McCONNEL



FRONT PTO SELECTOR**McCONNEL**


Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Front PTO Selector
1	4	4000759	WASHER
2	4	4004146	BOLT
3	1	4004331	SELECTOR
4	2	4000415	WASHER
5	1	4004332	BRACKET
6	2	4000066	BOLT
7	1	4004333	SPLIT FLANGE
8	24	4004328	BOLT
9	24	4000760	WASHER

SAFETY DECALS

Machine: ROBOPOWER

McCONNEL



SAFETY DECALS**McCONNEL**

Machine: ROBOPOWER

REF.	QTY.	PART No.	DESCRIPTION
			ROBOPOWER - Safety Decals
1	1	4000888	DECAL - EMERGENCY STOP
2	1	4000887	DECAL - 12 VOLT
3	1	4001367	DECAL - SAFETY WARNINGS
4	2	4000890	DECAL - BATTERY WARNINGS
5	4	4000891	DECAL - LIFT POINT
6	6	4000769	DECAL - GREASE POINT
7	1	4000892	DECAL - HYDRAULIC OIL
8	1	4000893	DECAL - DIESEL FUEL
9	1	4000894	DECAL - HOT SURFACE
10	1	4000895	DECAL - PROTECT FROM WATER
11	1	4000896	DECAL - LIFTING PROHIBITED



McConnel Limited, Temeside Works, Ludlow, Shropshire SY8 1JL. England.
Telephone: 01584 873131. Facsimile: 01584 876463. www.mcconnel.com